

# NUMERICAL INDEX

## KEY TO MODELS MENTIONED IN NUMERICAL INDEX

A — TRIUMPH HERALD	K — TRIUMPH G.T.6
B — ATLAS MAJOR & MINOR	L — TRIUMPH TR. 4 & 4A
C — VANGUARD VI	M — LEYLAND 2 TONNER
D — LEYLAND 15	O — TRIUMPH 2000
E — VITESSE	P — STANDARD 8, 10, PENNANT & 7 CWT.
E — 2 LITRE VITESSE	R — TRIUMPH TR. 2, 3 & 3A
F — SPITFIRE 4	T — VANGUARD III & SPORTSMAN
G — TRIUMPH TR. 5	V — LEYLAND 20
GA — TRIUMPH TR. 6	Y — ENSIGN & ENSIGN DE LUXE
J — VANGUARD I & II	Z — TRIUMPH 1300

Part No.	Description	Plate No.	Page	Also Used on Models
27110	Shim	B4	6	A,B,P,Z
27138	Shim	B4	6	A,B,P,Z
27378	Plug, core		4	A,B,E,E-2 litre,J,K,O,P,R, T,V,Y,Z
32307	Washer, felt	A49	3	A,B,E,E-2 litre,J,K,O,P,R,T, V,Y,Z
33214	Pin, anchor	B37	7	B,E,E-2 litre,K,O,P,Z
35960	Chain wheel	B22	6	B,E,E-2 litre,K,O,P,Z
36234	Filler piece	A25	2	B,E,E-2 litre,K,O,P,Z
36411	Plate	B24	6	A,B,E,E-2 litre,K,O,P,Z
37948	Shim	M12	23	A,B,E,E-2 litre,J,K,P,R,T,V,Y
38665	Balance fan piece	C27	9	A,B,E,J,P,T,V,Y
42243	Grommet	AD21	54	A,K,O,P,R,Y,Z
42244	Grommet	AD20	54	A,K,L,O,R,Y,Z
42425	Tensioner	B36	7	A,B,E,E-2 litre,K,O,P,Z
43752	Plate	B34	7	A,B,C,E,E-2 litre,K,P,Z
46172	Plug, core		1, 4	E,E-2 litre,K,L,M,O,P,Y,Z
46549	Plug		1	A,B,E,E-2 litre,K,L,O,P,Z
52413	Pin, mills	BF12	134, 136	A,E-2 litre,J,K,T,V,Y
52467	Head, filter cover	F3	13	A,B,P,Z
52469	Gauze, filter	F2	13	A,B,P,Z
52472	Gasket	F6	13	A,B,P,Z
52489	Screw	F24	13	A,B,M,P,V,Z
52490	Screw	F5	13	A,B,E-2 litre,J,K,L,O,P,R,T,V,Y,Z
52493	Spring	F20	13	A,B,M,P,V,Z
56177	Connector		70	O,P
56305	Screw		21	A,E,E-2 litre,J,K,L,R,T,V,Y
56712	Plug, core		1	A,B,E,E-2 litre,K,M,O,P
56934	Nipple		29	J,L,M,P,R,T,V,Y
57103	Gasket	C34	10	A,B,E,E-2 litre,J,K,O,P,R,T,Y,Z
57109	Ball pin	A84	5	A,B,E,J,O,P,R,T,V,Y,Z
57110	Nut	A85	5	A,B,E,E-2 litre,J,K,M,O,P,R,T,V,Y
57355	Washer	F21	13	A,P,Z
57361	Washer		13	A,B,E,E-2 litre,J,K,M,O,P,R,V,Y,Z
57458	Cover	AG25	58	A,B,C,E,K,O,P
57492	Brush spring	AJ4	62	
57591	Bulb	AK21	67	J,K,L,M
57602	Adaptor	AW14	101, 103	A,B,J,P,T,Y,Z
57868	Nut	BG99	138	J,L,O,R,T,V,Y
58258	Clamp	E12	12	A,B,J,L,P,R,T,V,Z
58261	Gaiter		29	A,E,P
58465	Fuse, 35 amp.		70	A,E,K,L,M,O,R,V,Y,Z
58923	Guide	A55	4	J,L,M,R,T,V,Y,Z
59115	Bolt	J14	18	B,E,E-2 litre,J,K,L,O,P,R,V,Y,Z

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
59191	Clip	Z32	48	A,D,E,J,K,L,O,P,R,T,Y
59380	Clip	Z2	47, 48	E,J,K,L,O,R,T,V,Y,Z
59426	Spanner		56	A,E,K,P,T,Y,Z
59445	Washer, rubber		73, 74, 101	A,B,E,J,K,L,M,P,R,V,Y
59467	Bulb, side	AL30	69	A,B,E,J,K,L,O,R,T,V,Y,Z
59474	Nut	BF45	135	A,E,E-2 litre,J,K,O,T,Y
59492	Bulb	AN8	72, 73	A,E,E-2 litre,K,L,M,O,P,Y,Z
59660	Screw	F10	13	A,B,E,E-2 litre,J,K,L,M,O,P,R, T,V,Y,Z
59813	Screw		70	A,E,K,O,P,V,Y,Z
59844	Defroster		145	A,E,J,O,P,R,T,Y
60070	Bush	T9	33	A,E,E-2 litre,K,P,V,Y
60176	Nut, tubing	AE14	13, 16, 55	A,E,E-2 litre,K,L,M,O,Z
60313	Bearing seal	C8	9	A,B,E,E-2 litre,J,K,L,M,O,R, V,Y,Z
61917	Grommet	AL39	13, 69, 74, 101, 105	A,B,E,E-2 litre,J,K,L,M,O,P, R,T,V,Y,Z
70391	Sundry parts set		58	A,E,J,K,L,O,P,R,T,V,Y,Z
100148	Clip	AM14	16, 55, 71, 72	E,K,L,M,R,Y
100431	Wheel, chain	B5	6	A,B,P,Z
100433	Stud	A19	2	A,B,E,E-2 litre,K,M,O,P,V,Z
100447	Deflector oil	B6	6	A,B,P,Z
100455	Nut	AD3	54	A,B,E,E-2 litre,K,O,P
100498	Nut	E15	12	A,B,E,E-2 litre,K,O,P,Z
100499	Seal, oil	B27	6	A,B,P,Z
100500	Screw, set	B23	6	A,B,E,E-2 litre,K,O,P,Z
100501	Screw	A26	2	A,B,E,E-2 litre,K,O,P,Z
100536	Bearing, hub	R22	30	A,B,L,Z
100562	Shim, .003"	T25	34	A,B,E,L,O,P,R,T,Y
100563	Shim, .005"	T25	34	A,B,E,L,O,P,R,T,Y
100564	Shim, .010"	T25	34	A,B,E,L,O,P,R,T,Y
100573	Bearing, hub	R19	29	A,B,L,P,Z
100764	Bearing	C11	9	A,B,E,E-2 litre,K,O,P,V,Z
100851	Circlip	C13	9	A,B,E,E-2 litre,K,O,P,V,Z
100996	Bolt	V5	39	A,B,E,P,Z
101022	Screw, set	A12	2, 4	A,B,O,P,Z
101089	Spanner		56	A,C,E,K,O,P,T,Y,Z
101092	Washer	C9	9	A,B,E,E-2 litre,J,K,L,M,O,P, T,V,Y,Z
101302	Nut	E29	12, 101, 103	E-2 litre,J,K,L,O,P,R,T,V,Y,Z
101343	Adaptor	E31	12, 101, 103	E,E-2 litre,J,K,L,O,P,R,T,V,Y,Z
101962	Stud	A18	9, 12	A,B,E,E-2 litre,K,O,P,Z
102689	Cap, grease retainer	R26	30	A,B,L,R,Z
102690	Washer, 'D'	R23	30	A,B,L,P,Z
102729	Sleeve, tubing	AE19	13, 16, 55	E,E-2 litre,K,L,M,O,Z
102986	Fan assembly	J2	18	A,B,J,L,M,P,R,T,V,Y
102987	Bush	U24	38	
104359	Nut		13	A,B,P,V,Y,Z
104420	Bush	M47	24	A,B,E,E-2 litre,K,P
104433	Ball, bearing	M4	23	A,B,E,E-2 litre,K,P
104438	Washer	M5	23	A,B,E,P
104445	Spring	M24	23	A,B,E,E-2 litre,K,P
104449	Plug, core	L42	21	B,E,E-2 litre,K,L,O,P,R,T,Y
104549	Shim		58	A,B,E,K,O,P
104552	Ball joint		29	P
104554	Bolt	T10	34	A,E,E-2 litre,K,P
104556	Bearing	T24	34	A,E,P
104557	Bearing	T27	34	A,E,P
104561	Shim	T28	34	A,E,P

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
104562	Shim	T28	34	A,E,P
104563	Shim	T28	34	A,E,P
104570	Washer	T19	34	A,E,P
104571	Gear	T20	34	A,E,P,Z
104572	Washer	T21	34	A,E,P,Z
104573	Pin	T22	34	A,E,P,Z
104581	Key	T77	36	A,E,E-2 litre,K,P
104582	Catcher, oil	T72	36	A,E,E-2 litre,K,P
104585	Bearing	T68	36	A,E,E-2 litre,K,P
104737	Pawl		49	A,E,G,K,O,P,Z
104738	Pin	AA3	49	A,E,K,L,P
104740	Spring	AA5	49	A,E,K,L,O,P,Z
104742	Ratchet	AA7	49	A,E,K,L,P
104743	Pin	AA8	49	A,E,K,P
104749	Fork-end	AA12	49	A,E,K,L,O,P,Z
104750	Pin	AA15	49	A,E,K,L,O,P,Z
104773	Housing	T70	36	A,E,E-2 litre,K,P
104775	Seal		41	B,P
104839	Spindle	C5	9	A,B,E,E-2 litre,K,O,P,Z
104840	Impellor	C7	9	A,B,E,E-2 litre,K,O,P,Z
104841	Piece, distance	C12	9	A,B,E,E-2 litre,K,O,P,V,Z
104859	Screw	A77	5	A,B,E,E-2 litre,K,O,P,Z
104860	Gear, driving	B52	8	A,B,P,Z
104861	Shaft	B53	8	A,B,P,Z
104862	Distributor and oil pump assembly	B51	8	
104863	Block, sealing	A24	2	A,B,E,E-2 litre,K,O,P,Z
104890	Bracket	J4	18	A,P,Z
104897	Pulley, dynamo	J3	18	A,B,E-2 litre,K,O,P,Z
104902	Dynamo pedestal	J12	18	A,P,Z
104903	Hose	AC32	53	A,B,C,K,P
104939	Washer, joint	B56	8	A,B,E,E-2 litre,K,O,P,Z
104963	Plug, core		11	A,B,E,E-2 litre,K,O,P
104964	Body assembly	D1	11	A,B,P
105114	Plate	B19	6	A,B,E,E-2 litre,K,O,P,Z
105115	Key	B8	6	A,B,P,Z
105118	Collar, valve	A69	4	A,B,E,P,Z
105120	Spring, rocker	A86	5	A,B,P,Z
105121	Stud	A16	2	A,B,P,Z
105123	Stud	A63	4	A,B,E,E-2 litre,K,O,P,Z
105124	Stud		4	A,B,E,E-2 litre,K,L,O,P,Z
105125	Stud		4	A,B,P,Z
105131	Chain, timing	B25	6	A,B,E,E-2 litre,K,O,P,Z
105143	Bush	B10	6	A,B,E,E-2 litre,K,P
105290	Clamp, plate	AD37	54	A,B,D,E,E-2 litre,J,K,L,M,O,P, R,T,V,Y
105292	Strip, flexible	AD35	54	
105321	Washer, joint	A30	2	A,B,E,E-2 litre,K,O,P,Z
105322	Spring, rocker	A88	5	A,B,E,E-2 litre,K,O,P,Z
105438	Nut	W2	40	A,E,E-2 litre,K,L,P
105605	Bush	Y2	43	A,B,E,E-2 litre,K,P,T,Y
105676	Cover bleed screw cap	AB28	51	A,D,E,E-2 litre,K,L,P,V,Y,Z
105689	Spring	AB38	52	A,E,E-2 litre,K,P,Z
105690	Spring	AB39	52	A,B,E,E-2 litre,K,P,Z
105760	Housing		9	A,B,P,Z
106036	Clip	AA18	49	A,B,E,K,P
106085	Spring	K10	19	A,B,K,L,M,P,R
106088	Retainer, spring	Y29	44	A,B,E,E-2 litre,K,L,P,R,V,Y,Z
106090	Washer, spring	Y27	44	A,B,E,E-2 litre,K,L,P,R,V,Y,Z
106092	Circlip	Y34	44	A,B,E-2 litre,K,L,P,R,V,Z
106094	Lid, reservoir	Y36	44	A,E,E-2 litre,K,L,P,Z

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
106095	Gasket	Y37	44	A,E,E-2 litre,K,L,P,Z
106155	Plunger	Y30	44	A,E,E-2 litre,K,P
106156	Spring	Y28	44	A,E,E-2 litre,K,L,M,P,R,V,Z
106157	Stem, valve	Y25	44	A,B,E,E-2 litre,K,L,P,R,V,Y,Z
106158	Seal, valve	Y24	44	A,B,E,E-2 litre,K,L,P,R,V,Y,Z
106254	Reverse operating lever assembly	M51	24	A,B,E,E-2 litre,K,P
106262	Washer	M15	23	A,E,E-2 litre,K,P
106268	Fork, selector	L48	21	A,B,E,E-2 litre,K,P
106269	Washer, joint	L56	21, 134	A,B,E,E-2 litre,K,P
106270	Washer, thrust	M42	24	A,B,E,E-2 litre,K,P
106271	Washer	M43	24	A,B,E,P
106365	Thrower	M33	24	A,B,E,E-2 litre,K,P
106388	Spring, plunger	M11	23	A,B,E,E-2 litre,K,P,R
106437	Gasket	L36	21, 134	A,B,E,E-2 litre,K,P
106448	Fulcrum	M52	24	A,B,E,E-2 litre,K,L,P,O
106475	Pin	M9	23	A,B,E
106476	Screw	M44	24	A,B,E,P
106477	Screw	M49	24	A,B,E,E-2 litre,K,P
106478	Pin	L51	21	A,B,E,E-2 litre,K,P
106481	Plunger	L53	21	A,B,E,E-2 litre,K,L,O,P,V
106489	Spring	L55	21	A,B,E,E-2 litre,K,L,O,P,V
106663	Split cone	A72	4	A,B,E,E-2 litre,K,L,M,O,P,R,V
106664	Washer	T71	36	A,E,E-2 litre,K,P
106957	Stud	L40	21	A,E,E-2 litre,K,P,R
107072	Gasket	Z15, Z29	48	A,B,E,K,L,M,P,R,V,Y,Z
107099	Plug	L43	21	A,B,E,E-2 litre,K,P
107176	Seal	AB23	51	A,B,E,E-2 litre,K,L,P,R,V
107193	Seal	T69	36	A,E,E-2 litre,K,P
107246	Plug	A52	3	A,B,E,E-2 litre,K,O,P,Z
107401	Dowel	B42	7	A,B,E,E-2 litre,K,O,P,Z
107530	Stud	E4	12, 16	
107948	Nut	V13	39	E,K,L,R
107949	Nut		39	E,K,L,R
108020	Shaft, selector	L44	21	A,B,E,P
108021	Shaft, selector	L45	21	A,E,E-2 litre,K,P
108301	Spring	G26	14	L,R
108302	Screw	G51	15	L,R,T
108325	Nut	G58	16	A,L,R,T
108334	Pin	G47	15	A,L,R,T
108341	Spring	G21	14	A,L,R
108349	Screw	G5	14	A,L,R,T
108350	Bolt	G56	16	A,L,R,T
108351	Washer	G52	15	L,R,T
108355	Spring	G8	14	R,T
108450	Mallet		39	E,K,L,R
108657	Brush	AH2	60	A,E,K,L,P,Z
108756	Screw, bleed	AB27	51	A,B,E,E-2 litre,K,L,P,R,V,Y,Z
108757	Seal, oil	L34	21	A,B,E,E-2 litre,K,O,P
108860	Casing	AJ18	63, 64	A,B,E,K,L,O,P,R,T,V,Y
108935	Washer, thrust	T21	34	
108936	Washer, thrust	T21	34	
108937	Washer, thrust	T21	34	
108938	Washer, thrust	T21	34	
108939	Washer, thrust	T21	34	
108943	Clamp	AWS47	102, 104	K
108976	Bolt	W17	40	A,E,K,P,T,Y,Z
108977	Bush, rubber	W15	40	A,E,K,P,T,Y,Z
108979	Gear	T18	34	A,E,P
109023	Rocker, No. 1	A82	5	A,B,E,O,P,Z
109024	Rocker, No. 2	A83	5	A,B,E,O,P,Z

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
109049	Nut	T32	34	A,B,E,P
109050	Flange	M28	23	A,B,E,P
109054	Seal	T29	34	A,E,P
109182	Rod push	L22	20	
109190	Seal	Y31	44	A,E,E-2 litre,K,P
110376	Pin	T23	34	A,E-2 litre,K,P,Z
110461	Strip, conductor	W19	40	A,E,K,P,Z
110679	Washer	G28	14	L,R
110748	Nut	A65	4	A,B,E,E-2 litre,K,O,P,Z
110907	Spacer	T26	34	A,E,P
110960	Plate	W14	40	A,E,K,P,Z
111054	Tappet, adjuster unit	AB19	51	A,D,E-2 litre,K,L,P,Y
111163	Spacer, valve	Y26	44	A,B,E,E-2 litre,K,L,M,P,R,V,Y,Z
111422	Washer, thrust	M19	23	A,B,E,E-2 litre,K,P
111423	Bush	M18	23	A,B,E,E-2 litre,K,P
111424	Bush	M17	23	A,B,E,P
111870	Valve spring collar, upper	A71	4	A,E,E-2 litre,K,O
111874	Push rod	A74	4	A,B,P,Z
111979	Seal, taper	Y32	44	A,E,E-2 litre,K,P
112394	Circlip	M22	23	A,B,E,E-2 litre,K,P
112429	Stud	R24	30, 36	A,E,E-2 litre,K,P,Z
112477	Bush	M40	24	A,P
112509	Plug	L20	20	A,B,P
112516	Pin, push rod to lever	L23	20	A,B,P
112626	Gasket	BF8	134	E,E-2 litre,K,P
112654	Circlip	M7	23	A,B,E-2 litre,K,P
112672	Gear, 2nd speed	M16	23	A,P
112907	Stud	A21	2	A,L,O,R,T
113071	Spindle	M48	24	A,B,E,E-2 litre,K,P
113077	Reverse idler gear assembly	M46	24	A,B,P
113087	Nut, wheel	V8	39, 107	A,E,K,Z
113150	Bolt	AB14	51	A,E,E-2 litre,K,L,R
113229	Washer, thrust	M41	24	A,B,E,E-2 litre,K,P
113230	Countershaft	M38	24	
113256	Medallion assembly		143	E,L,O,R
113797	Cup	M14	23	A,B,E,E-2 litre,K,P
113868	Fork, selector	L47	21	A,B,E,E-2 litre,K,P
114006	Button, thrust	U3	37	A,E,K,T,Y
114092	Bracket		13, 16	E,Z
114178	Grommet	AE25	16, 55	E-2 litre,K,O
114210	Bracket, 4 way		27	K,L
114438	Spring	Y7	43	A,B,E,E-2 litre,K,O,P,V
114749	Washer	T34	34	A,E,E-2 litre,K,P
114774	Plug, taper	A43	3, 4, 20, 33	A,B,E,E-2 litre,K,L,M,O,P,R,T, V,Y,Z
114781	Actuator, reverse	L49	21	A,E,P
115459	Hose, rear	Z28	48	K,Z
115706	Boot, rubber		71	E,K,O,T,V,Y,Z
115783	Connector		13, 16	A,B,E,K,O,P,R,V,Z
116169	Gear, 3rd speed	M20	23	A
116201	Gasket	Y53	44	K,L,M
116516	Plug, core	A5	1	A,M,O,P,V,Y,Z
117509	Washer	M2	23	A,B,E,E-2 litre,K,P
117510	Seal oil	L31	21	A,B,E,E-2 litre,K,P
117511	Bearing	L30	21	A,B,E,E-2 litre,K,P
117547	Cap, bearing	T41	35	A,E
117575	Bush, rubber	U2	37	A,E,K
117578	Bush		33	A,E,E-2 litre,K
117853	Bearing	T61	35	A,E,E-2 litre,K
117948	Bearing, ball	T38	35	A,E

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
117952	Seal, oil	T42	35	A,E,E-2 litre,K
118040	Lever, gear, internal	N27	25	A,E,K,P
118041	Shaft, gear lever	N26	25	A,E,P
118053	Seal, oil	N29	25	A,E,K,P
118054	Screw	N19	25	A,E,K,P
118507	Bearing, needle roller	M32	24	A,B,E,P
118599	Pin, fulcrum	U25	38	A,E,K
118632	Plug	A6	1	A,B,E,E-2 litre,K,M,O,P,T,V,Y,Z
118826	Plug, core		33	A,E,E-2 litre,K,L,O,Z
118977	Washer	Q30	28, 33	E,E-2 litre,K,L,O,P,R,T,Y,Z
119072	Rim	AK1	65, 66	K,L,M,O,R
119096	Bearing		21	A,E,E-2 litre,K
119099	Seal, oil	L35	21	A,E,E-2 litre,K
119100	Gear	L32	21	A,E,E-2 litre,K
119131	Gear	M3	23	A,E,E-2 litre,K
119142	Bolt	R47	30	E,E-2 litre,K
119251	Spring	N8	25	A,E,K,P
119252	Spring	N6	25	A,E,K,P
119262	Bush	N14	25	A,E,K,P
119263	Circlip	N7	25	A,E,K,P
119272	Top wishbone arm and bush	R1	29	A,E,E-2 litre,K
119450	Bush, rubber	R53	31	A,E,E-2 litre,K,L,Z
119451	Bush, rubber	R2	29, 30, 37	A,E,E-2 litre,K
119573	Washer	N10	25	A,E,K,P
119575	Shaft pedal	Y3	43	A,E,E-2 litre,K
119583	Bracket	Y59	45	A,E,E-2 litre,K
119616	Flasher warning light		73	A,B,E,V,Y
119813	Bush, small end	B41	7	A,E,E-2 litre,K,L,O,P
120116	Piston	AB24	51	A,B,E,P
120124	Pin	AB35	52	A,B,E,E-2 litre,K,P,R
120128	Dust cap	K17	19	A,B,D,M,P
120132	Rear wheel cylinder assembly		51	A,B,E,P
120134	Cover, dust	AB25	51	A,B,E,E-2 litre,K,P
120135	Retainer, dust cover	AB26	51	A,E,K,P
120137	Spring, plate	AB30	51	A,B,E,E-2 litre,K,P,Z
120138	Plate, retaining	AB29	51	A,B,E,E-2 litre,K,P,Z
120139	Cover, dust	AB33	52	A,B,E,E-2 litre,K,P
120142	Adjuster unit assembly	AB18	51	A,B,D,E,E-2 litre,K,L,P,R,Y,Z
120305	Washer	N30	25, 134	A,E,K,P
120307	Plate	N2	25	A,E,K,P
120308	Master cylinder assembly		44	A,E,E-2 litre,K
120327	Washer, thrust	T39	35	A
120331	Connection		16	E-2 litre,L,O,R
120694	Angle drive	BF49	135	E,E-2 litre,K,L,O
120941	Shim		41	A,E,K,L,O
120946	Plunger	W32	41	A,E,K,L,O
120948	Bellows	W45	41	A,E,K,L,O,Z
120949	Shim	W34	41	A,E,K,L,O,Z
120953	Spring	W42	41	A,E,K,L,O,Z
120955	Socket, ball	W39	41	A,E,K,L,O,Z
120957	Washer, tab	W40	41	A,E,K,L,O,Z
120959	Shim	W34	41	A,E,K,L,O,Z
121215	Dynamo link lifting eye	J16	18	A,B,P,Z
121217	Cylinder head stud	A17	2	A,B,P,Z
121269	Starter solenoid switch	AG31	59	A,E,K,L,O,Y,Z
121295	Nut, wheel	V14	39	E,K,L
121296	Nut, wheel		39	E,K,L
121297	Spanner		39	E,K,L
121398	Oil pressure indicator switch	A34	2	A,B,E,E-2 litre,K,M,O,P,V,Z
121530	Distributor pedestal	B55	7	A,E,P,Z

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
121699	Compensating sector	AA29	50	A,E,K,O
121755	Seal, dust (Rubber)	AA26	50	A,E,K
121757	Bearing	AA24	50	A,E,K
121758	Washer, tab	AA28	50	A,E,K
121759	Pin, shouldered	AA27	50	A,E,K
121760	Seal, felt	AA25	50	A,E,K
121765	Bracket, fulcrum	AQ2	78	A,E,K,L
121766	Handbrake cable assembly	AA11	49	A,E,K
121770	Flange	T30	34	A,E,P
121782	Connector	Z19	48	A,B,E,K,L,V,Z
121831	Tube, dipstick	A15	2	I,M,V
121860	Washer, tab	T74	36	A,E,E-2 litre,K
121862	Bolt	T73	36	A,E,E-2 litre,K
122022	Shim	R40	30	A,E,E-2 litre,K
122115	Water pump plug	C4	9, 35	A,B,E-2 litre,K,O,P,Z
122126	Oil seal	R50	30	A,E,E-2 litre,K,L
122137	Plate, spring	R56	32	A,E,E-2 litre,K
122289	Pad, rubber	Y5	43	A,E-2 litre,K,L,R,Z
122296	Rod, push	Y33	44	A,E,E-2 litre,K
122534	Dirt seal	R45	31	A,E,E-2 litre,K
122566	Clutch cover, front end	L6	20	A,P
122569	Washer, joint	L14	20	A,B,E,E-2 litre,K,P
122653	Screw, set	L50	21, 25	A,B,E,E-2 litre,K,L,M,O,P,V,Y
122669	Clamp, steering column	W8	40	A,E,K,L
122689	Rear engine mounting	P6	26	A,E,K
122718	Cap, end	W6	40	A,E,K,L
122719	Washer, bearing	W7	40	A,E,K,L
122745	Spanner		56	A,E,K,Z
122746	Pouch, tool		56	A,E,K,O
122747	Clip	Q26	27	K,L
122796	Connector tank	AE20	55	A,E
122806	Plate, nave	V19	39, 143	A,E,K
123100/4	Rear damper (Armstrong)		38	
123100/5	Rear damper (Girling Monitube)	U23	38	
123135	Operating lever assembly	AB31	52	A,E,E-2 litre,K,P
123203	Plate, stiffening		28	A,K
123231	Cap, spring, plate	R57	32	A,E,E-2 litre,K,Z
123415	Gasket, exhaust pipe	AD2	54	E,E-2 litre,K,O,T
123495	Hose, feed	E23	12	
123502	Bracket	S3	32	A,K,Y
123803	Screw	T43	35	A,E,E-2 litre,K
123813	Shim, .009"	T14	33	A,E,E-2 litre,K
123814	Shim, .013"	T14	33	A,E,E-2 litre,K
123815	Shim, .014"	T14	31	A,E,E-2 litre,K
123817	Shim, .020"	T14	33	A,E,E-2 litre,K
123998	Bush	S2	32	A,E,K
125054	Bolt	N17	25	A,E,K,P,V
125074	Stud	S9	32	A,E,K
125217	Cover, dust	Y11	43	A,E,E-2 litre,K
125252	Washer, joint, pedestal to cylinder block	B56	7	A,B,P,Z
125481	Link assembly, R.H.	S7	32	A,K
125482	Link assembly, L.H.	S8	32	A,E,K
125505	Feeler gauge assembly		56	A,E,L,P,Y,Z
125733	Strut	R32	30	A,E,E-2 litre,K
125781	Screw, locating	W10	40	A,E,K,L
125782	Plate, locating	W9	40	A,E,K,L
126607	Cap, top cover extension	N11	25	A,E,K
126754	Dowel, gear control	N12	25	A,K
126765	Spring	W33	41	A,K,L,O
126792	Relay, overdrive	BF39	135	E-2 litre,K,L,O,R,Y

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
126893	Inlet valve	A67	4	A
127380	Switch	BF43	135	A,E-2 litre,K,L,O,Y
127651	Ignition and starter switch	AN19	73	A,K,L,O,Z
127740	Shaft		134	E-2 litre,K
127741	Coupling	N21	25	A,K
127883	Dowel	B14	6	Δ,E-2 litre,K,L,O,P,V,Y,Z
127916	Rear number plate lamp		69	Δ,K,L
127997	Bush	W24	40	A,K,L,O
127998	Bush	W28	41	A,E,K,L,O
127999	Washer	W27	40	A,E,K,L,O
128000	Washer	W25	40	A,E,K,L,O
128001	Plug	W30	40	A,E,K,L,O
128002	Bush		40	A,E,K,L,O,Z
128004	Bellows	W44	41	A,E,K,L,O,Z
128008	Pin		41	A,E,K,L,O
128020	Cover, end		40	A,E,K,L,O
128021	'O' ring	W29	41	Δ,E,K,L,O,Z
128022	Nut, lock	W51	41	A,E,E-2 litre,K,L,O,Z
128023	Pin, ball	W38	41	A,E,K,L
128024	Housing	W37	41	A,E,K,L,O,Z
128058	Nut	B9	6	A
128087	Washer	AN21	73	C,E,L,O
128088	Washer	AN41	60, 74, 101	C,E,L
128089	Washer		74, 102	A,C,D,E,G,O
128135	Shaft		35	A,E-2 litre,K
128136	Flange		35	A
128262	Sleeve		16	Δ,C,E,E-2 litre,K,L,O,P,Z
128348	Bolt		143	A,F
128352	Plate	U4	37	A,K
128356	Shim	Q34	28	A,E,K
128373	Washer	N9	25	A,E,K
128397	Rear number plate lamp	AL28	69	A,K,L
128404	Plug		18	E,E-2 litre,K,O,Z
128469	Flinger		35	A,E-2 litre,K
128484	Voltage stabiliser	AN2	72	A,C,E,E-2 litre,K,L,M,O,Y,Z
128572	Bearing, ball		35	A,E,K
128651	Circlip	T56	35	A,E
128889	Oil filter assembly	D6	11	A,P,Z
128921	Oil pump complete		11	A,P
128978	Oil seal	T62	35	A,E,E-2 litre,K
129003	Outer axle shaft and flinger	T54	35	A
129119	Sleeve	N16	25	A,B,E,K,V
129242	Plug	R11	29	E,E-2 litre,K,Z
129358	Bush	L26	20	A,P
129361	Bolt	T57	35, 39, 135	A,E
129410	Pin	L28	20	A,P
129412	Ring	L27	20	A,P
129650	Plate	Q31	28	A,K
129781	Bolt	T16	33	A,E,E-2 litre,K,P,Z
129952	Shaft	N13	25	A,E,K
129961	Inner ball joint assembly		41	A,E,K,L
129963	Sleeve adaptor	W41	41	A,E,K,L,O,Z
130031	Shim, .002"		41	A,E,K,L,O,Z
130032	Shim, .010"		41	A,E,K,L,O,Z
130141	Screw		145	
130142	Washer, tab		145	
130148	Adaptor		145	
130355	Differential bearing	T13	33	A,E,E-2 litre,K,P
130415	Washer, joint	H3	17	
130544	Switch	AN24	73	E,L,O

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
130545	Washer	AN26	73	E,O
130757	Bracket	R34	30	A,E,E-2 litre,K
130758	Bracket	R35	30	A,E,E-2 litre,K
130814	Insert	A58	4	C,E,E-2 litre,K,O,P,Z
131155	Grommet	AJ19	63, 64	K,L,O
131169	Screw, self tapping		70	C,E,K,Y,Z
131251	Flasher unit	AH14	60	E,K,L,M,O
131312	Grip, handbrake lever	AA6	49	A,E,K,L,M,O,Z
131535	Spring	A51	3	A,E,E-2 litre,K,O,P,Z
131567	Rear hub and stud	T75	36	A,E-2 litre,K
131570	Packing		58	A,E,K,O,P
131608	Front flasher lamp (White lens)		68	K,V
131786	Bush	A11	2	A,P,Z
131796	Rubber, lower	T50	35	A,E,E-2 litre,K,O
131806	Spring	AA40	50	A,D,E,K,V
131807	Plate	AA41	50	A,E,K,Z
131809	Back plate, R.H.		51	A
131810	Back plate, L.H.	AB17	51	A
131812	Switch	AN29	73	L
131843	Washer, thrust		23	A,E,K
132053	Cap	W35	41	A,E,K,L,O
132055	Shim, .010"	W34	41	A,E,K,L,O,Z
132068	Nut, wing		81	E,F,K,O,V,Y,Z
132098	Ring	D7	11	A,P,Z
132104	Bracket, R.H.		27	A,E,K
132105	Bracket, L.H.	Q4	27	A,E,K
132107	Piston	A50	3	A,E,E-2 litre,K,O,P,Z
132115	Stud	BF1	134	E,E-2 litre,K
132135	Lock and ignition switch		146	
132242	Valve insert, exhaust	A59	4	A,P,Z
132365	Bracket, R.H.	Z12	47	A
132366	Bracket, L.H.	Z13	47	A
132368	Spanner		56	A,K,O
132419	Washer	T52	55	E-2 litre,K
132435	Bracket	Q18	27	A,E,K
132439	Bolt	AB11	51	A,E,E-2 litre,K,Z
132495	Stud	A62	4	A,C,E,E-2 litre,K,L,O,P,Z
132565	Tap	AC3	53	K,L,Z
132586	Lever	AA1	49	A,E,K
132588	Rod assembly		49	K,O
132589	Handbrake assembly		49	A,E,K
132649	Inner axle shaft	T37	35	A
132650	Circlip	T40	35	A
132664	Seal, oil	R18	29	A,D,E,E-2 litre,K,P
132668	Seal, oil		29	E,E-2 litre,K
132754	Bracket assembly	Q24	27	K
132763	Rear vertical link assembly, R.H.		37	A,E,K
132764	Rear vertical link assembly, L.H.	U19	37	A,E,K
132819	Bracket assembly	Q25	26	
132856	Bolt	T6	33	A,E-2 litre,K,L
132872	Bolt		22	A,E-2 litre,K,O
132958	Hose	Z14	48	A,L
133065	Radius arm	U14	37	K
133068	Pivot bracket		37	K
133069	Pivot bracket	U10	37	K
133070	Shim	U12	37	K
133103	Plug	W36	41	A,E,K,L,O,Z
133122	Bracket		27	K
133148	Cover	D3	11	A
133322	Switch	AN40	60, 74, 101	E,L

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
133331	Hose, bottom	AC34	53	A
133450	Bracket	Y60	45	
133524	Bush, rubber		38	K
133568	Mounting rubber, upper	T49	35	A,E-2 litre,D,K
133581	Cap, filler		44	K
133582	Seal, adaptor	Y54	44	K
133770	Bracket assembly	BF46	135	E-2 litre,K
133771	Arm assembly	BE11	134	E-2 litre,K
133875	Plate	W54	41	A,E-2 litre,K,O
133915	Cable assembly	AA33	50	K
133919	Mounting bracket assembly		78	K
134001	Rod assembly	AA4	49	K
134056	Pipe assembly	Z11	47	A
134072	Pin, cross	T22	34	A,E,K
134073	Gear, differential, 16 teeth	T18	34	A,E,K
134074	Pinion, differential, 10 teeth	T20	34	A,E,K
134075	Washer, thrust	T19	34	A,E,K
134076	Washer, thrust	T21	34	A,E,K
134143	Pawl	AA2	49	K,L
134216	Bracket assembly	BF13	134	E
134229	Mounting, flexible	BF15	134	E,E-2 litre,K
134243	Temperature gauge	AN6	72	E-2 litre
134253	Handbrake assembly		49	K
134290	Shaft	L46	21	A,E
134336	Tool, wheel		39, 56, 143	E,O
134399	Outrigger, R.H.	Q13	27	K
134400	Outrigger, L.H.	Q14	27	K
134503	Brake pedal	Y12	43	K
134504	Clutch pedal	Y1	43	K
134529	Switch		70	A,E-2 litre,L,M,O,Z
134532	Bracket	Y17	43	A,E-2 litre,K
134540	Bearing	X11	42	E,K,M
134574	Washer, sealing	AE7	55	K,O,Z
134575	Ring, locking	AE8	55	K,O,Z
134580	Bracket	Q10	27	K
134681	Water elbow	C33	10	O,Z
134688	Pinion, L.H.S.		40	A,E,L
134689	Pinion, R.H.S.	W26	40	L
134746	Wheelbox	AJ12	63	K
134747	Bush	AJ13	63, 64	K
134748	Bush	AJ15	63, 64	K
134751	Seal, rubber	AJ14	63, 64	K
134757	Trip, flex	AN3	72	K
134814	Gear control hand lever	N4	25	
134855	Carburettor fuel pipe		16	
134862	Relay lever assembly	AA23	50	A,K
134886	Lead, engine, No. 1		18	Z
134887	Lead, engine, No. 2		18	E,E-2 litre,K,O,Z
134888	Lead, engine, Nos. 3 and 4		18	Z
134890	Lead, earth		70	
134891	Arm clamp assembly	AF26	57	E
134933	Dipstick assembly	A48	3	
134936	Washer	G67	16	
134942	Nut	AE18	55	
134953	Washer, felt	X12	42	
136487	Spring	A70	4	A,E
136600	Ball joint assembly	W48	41	A,E-2 litre,K
136604	Ball joint assembly	R5	29	A,E-2 litre,K
136711	Platform assembly	BE14	134	
136818	Stud	T45	35	

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
136835	Spring	X28	42	
136868	Piece, distance		27	K
136869	Bolt	T46	35	K
136885	Clamp assembly	W53	41	E-2 litre,K,L,O
136890	Bracket assembly	P7	26	A,K
136908	Connection, three-way	Z21	47, 48	A,E,K,L,V,Z
136939	Connection	Z4	47	A,E,K,L,Z
136979	Link	X29	42	
136990	Plunger	L54	21	A,E,E-2 litre,K
137015	Bracket	X4	42	K
137048	Clip	Z10	47	A,K,L,O
137308	Spring, ring	BG19	136	E,E-2 litre,K
137474	Horn assembly, high note		60	
137531	Balance weight, ½ oz.		145	L,O,Z
137622	Bracket	J7	18	A,Z
137632	Bottle	AC23	53	E,K,L,O,Z
137691	Cap	AC2	53	E,K,L,O,Z
137705	Temperature transmitter	AN7	72	E-2 litre,K,O,Z
137743	Cap	AC24	53	E,K,L,O,Z
137747/1	Horn relay		60	K,L,O
137747/2	Horn relay		60	K,L,O
137795	Control unit		141	A,O
137797	Warning light, control unit	BK11	141	A,O
137811	Plug	A89	5	Z
137842	Bracket assembly	Y6	43	A,E-2 litre,K
137845	Clamp	E13	12	Z
138092	Bearing	L33	21	A,E
138211	Bearing, big end	B44	7	Z
138316/I	Cable, inner, L.H.S.		72	E,K
138316/O	Cable, outer, L.H.S.		72	E,K
138317/I	Cable, inner, L.H.S.	AN12	72	
138317/O	Cable, outer, R.H.S.	AN13	72	
138322	Extension	BF36	135	
138323	Extension	BF36	135	K
138380	Plug		2	
138440	Washer, thrust	T21	34	A,E,K
138441	Washer, thrust	T21	34	A
138442	Washer, thrust	T21	34	A,E,K
138478	Wiper blade	AJ21	63	K
138479	Wiper arm, R.H.S.	AJ20	63	K
138480	Wiper arm, L.H.S.		63	K
138526	Bolt	B15	6	A,C,E,E-2 litre,K,O,Z
138529	Bolt	B43	7	A,C,E,E-2 litre,K,O,Z
138530	Adaptor	E21	12	E-2 litre,K,L,O,Z
138556	Stub axle	R15	29	A
138558	Bolt	R28	30	A,O
138559	Water shield	R14	29	A,E,E-2 litre,K
138591	Washer		13	A,M,V
138608	Grommet	Z35	48	
138685	Bush	N5	25	A,E,K
138686	Bush	N15	25	A,E,K
138701	Gasket	C18	9	A,C,E,E-2 litre,K,O,Z
138702	Washer	C21	9	A,Z
138737	Cigarette lighter		145	O
138807	Clip	AD12	54	E-2 litre,K,L,O
138892	Clip		16	A,C,E,E-2 litre,K,O,Z
138926	Operating valve	BG11	136	E-2 litre,E,K
139029	Washer	A93	5	A,Z
139126	Bracket	S4	32	K
139286	Cover	A40	4	O

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
139386	Mounting rubber	W52	41	E-2 litre,L,O,Z
139521	Bracket	Q21	27	A,E
139522	Bracket	Q22	27	A,E
139523	Pipe assembly	Z27	48	A,E,K
139530	Cap, bearing		3	A,E,K
139532	Circlip		35	A,E,K
139563	Sleeve	L25	20	
139572	Bearing	L24	20	
139827	Bracket	AD17	54	K
140039	Finisher		145	A
140073	Balance weight, 1 oz.		145	L,O,Z
140074	Balance weight, 1½ oz.		145	L,O,Z
140075	Balance weight, 2 oz.		145	L,O,Z
140111	Bearing, main	B2	6	Z
140472	Bracket		145	
140473	Bracket, mounting, R.H.		145	
140549	Clip	W4	40, 146	E,K,L,Z
140567	Ammeter		141	
140600	Hose		145	
140601	Hose		145	
140727	Washer	M21	23	E,K
140755	Steering column, upper assembly	W3	40	E,K
140797	Ring	B46	7, 8	Z
140798	Ring	B47	7, 8	Z
140799	Ring	B48	7	Z
140892	Bearing	R42	30	E,E-2 litre,K
140893	Piece, distance	R44	30	E,E-2 litre,K
140894	Water shield	R43	30	E,E-2 litre,K
140895	Water shield	R46	30	E-2 litre,K
140919	Bottom trunnion assembly, R.H.		30	E,E-2 litre,K
140920	Bottom trunnion assembly, L.H.	R41	30	E,E-2 litre,K
140970	Thermostat unit (82 degrees opening)	C32	10	E,E-2 litre,K,L,O,Z
140987	Union		145	
141185	Seal, dirt	T66	35	E,E-2 litre,K,L
141218	Bearing	T65	35	E,E-2 litre,K
141221	Piece, distance	T63	35	E,E-2 litre,K
141443	Shim	T67	35	E,E-2 litre,K
141444	Shim	T64	35	E,E-2 litre,K
141475	Pipe	AC31	53	
141606	Bracket	AC25	53	
141625	Steering column, upper assembly		40, 146	E,K
141648	Strip	H4	17	
141675	Flywheel assembly	B11	6	
141709	Air cleaner	H2	17	
141761	Battery		70	
141998	Hose	E25	12	E
142087	Angle, battery retaining		81	K,Z
142134	Link, alternator adjusting	BJ8	140	A
142139	Adaptor	W16	40	K,Z
142140	Flexible joint assembly		40	K,Z
142169	Ignition relay		141	A,G,O
142251/1	Horn, high note	AH4	60	
142251/2	Horn, low note		60	L,O
142252/1	Horn, windtone, low note	AH5	60	
142252/2	Horn, windtone, high note		60	L
142281	Clip	AD6	54	K
142333	Washer	T78	36	Z
142440	Plug	A10	1	Z
142500	Lever assembly	X14	42	
142540	Lead		60	

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
142597	Hub adaptor, R.H.	V11	39	E,K
142598	Hub adaptor, L.H.		39	E,K
142621	Bracket		141	
142647	Bearing	B17	6	
142648	Bearing	B18	6	
142649	Lifting eye bracket	A97	4	Z
142774	Washer	A27	2	Z
142795	Nut, lock	W43	41	E-2 litre,K,L
143345	Terminal blade starter, solenoid		135	
143393	Cap	A92	5	E-2 litre,K,L,O
143456	Seal	A29	2	
143537	Bezel		74, 102	A,E,G
143552	Valve tappet	A73	4	E-2 litre,K,O,Z
143775	Fan assembly, alternator		139	A,K,O
143802	Nut, self locking	BJ7	140	
143952	Washer, packing		41	A,E,O
144070	Stud		4	
144095	Knob, gear lever		25	E,K,Z
144123	Clip		59	Z
144254	Loctite		12	Z
144278	Rear damper		38	K
144297	Body, water pump	C1	9	Z
144326	Bracket		28	
144504	Nut	V12	39	A,K
144542	Pipe assembly	AE21	55	
144648	Plug	A56	4	
144656	Cable	AL40	69	K
144686	Plug, core	A8, A57	1, 4	
144687	Plug, core	A9	1	
144688	Plug, core	A7	1	
144716	Clutch slave cylinder		19	
144781	Washer, thrust	B3	6	Z
144962	Rocker shaft	A75	5	Z
144965	Valve, exhaust	A68	4	
144973	Pedestal	A79	5	Z
144974	Pedestal	A78	5	Z
144975	Pedestal	A76	5	Z
145108	Plug, nylon		46	K,L,O
145197	Spring	G66	16	
145319	Pad	AB5	51	Z
145890	Clip	AH22, AN38	61, 70, 74	E-2 litre,K,Z
145891	Sleeve		72	G,O,Z
146092	Gasket	E10	12	Z
146112	Coil, ignition	AF34	57	E-2 litre,K,O
146251	Horn, low note		60	O
146257	Super post horn		60	O
146303	Washer, plain		25	A,K
146305	Lead		70	K
146326	Tap, water drain		2	A,GA,O
146366	Pouch, tool		56	K,O
146413	Bracket support		45	
146422	Brake master cylinder assembly		44	
146423	Brake master cylinder assembly		44	
146431	Thermostat unit (88 degrees opening)		10	E-2 litre,K,O
146470	Piston assembly	B45		Z
146471	Piston assembly		7	Z
146479	Hub, front	R20	30	
146485	Pin, gudgeon	B49	7, 8	Z
146543	Connecting rod assembly	B40	7	
146728	Ball joint assembly		41	Z

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
146821	Cable, inner	AN32	74	
146825	Cable, outer	AN33	74	
146873	Ring		7, 8	
146914	Washer	A87	5	Z
146951	Front brake caliper assembly, L.H.	AB1	51	
146952	Front brake caliper assembly, R.H.		51	
146987	Bezel	AN34	74	
147119	Emission control valve	E19	12	Z
147249	Washer, thrust	T21	34	A,E,K
147250	Washer, thrust	T21	34	A,E,K
147251	Washer, thrust	T21	34	A,E,K
147252	Washer, thrust	T21	34	A,E,K
147277	Flasher indicator switch	AH19	61	
147278	Lighting switch head, dip	AH23	61	
147279	Lighting switch head, dip		61	
147280	Switch, overdrive	BF54	135	
147281	Switch, overdrive		135	
147333	Fan, dynamo pulley		18	A,E,K,O
147414	Hose, control	E20	12	
147463	Driven plate assembly	K18	19	
147466	Body, harness		70	
147467	Lead		18	
147471	Reverse light switch	AM10	71	
147474	Washer, alum	N23	25	A,E,K
147483	Spacer	BJ5	140	A
147530	Pulley, alternator		139	A,G,K,O
147547	Side and flasher lamp		67	
147548	Side and flasher lamp		67	
147549	Gasket	AK25	67	
147550	Rear flasher lamp, red lens		68	
147551	Rear flasher lamp, amber lens		68	
147552	Gasket	AL15	68	
147553	Bezel	AL16	68	
147592	Plinth	AL17	68	
147604	Fuel gauge	AN5	72	
147621	Lead set		146	
147622	Lever, throttle	G53	16	
147630	Plate, support, overdrive		134	K
147632	Mounting, rear engine		134	K
147668	Harness	BE34	135	
147747	Pipe assembly, rear L.H.S. only		47	K
147748	Pipe assembly, front L.H.S. only		47	K
147775	Cover, top	L39	21	
147777	Lead, reverse	AM12	71	
147788	Support assembly	Q8	27	
147789	Support assembly	Q9	27	
147791	Bracket, front	AD5	54	
147861	Plate, mounting	E16	12	
147899	Alternator bracket	BJ1	140	A,G,O
147906	Pulley, dynamo		18	A,E,K,O
147911	Steering column locking device and ignition switch kit		146	
147912	Strap		99, 146	
147951	Bolt		99, 146	
147972	Fan assembly, 4 blade	C25	9	A
147993	Bush	T3	33	
148030	Gear train assembly		23	
148043	Piston assembly		7	
148044	Piston assembly		8	
148083	Segment, ratchet		49	A,G,K

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
148156	Tandem brake master cylinder bracket	YA29	46	K
148322	Seal	C6	9	A,E,G,O,Z
148353	Plug		1	A,G,K,O,Z
148388	Valve, exhaust		4	
148576	Hazard flasher unit		60	G,K
148644	Flasher unit		60	G,K
148646	Lead, loop		61	K
148647	Lighting switch, headlamp dip and flash, L.H.S.		61	K
148648	Lighting switch, head, dip and flasher		61	E
148805	Washer, thrust	T21	34	A,K
148830	Hazard warning light		73	G,K
148897	Platform		134	
148957	Plug, sparking		18, 144	G,K
148971	Cap, filler		53	Z
149074	Driven plate assembly		19	
149117	Inner axle shaft assembly		35	A
149137	Tube, P.V.C.		74	K
149265	Disc		14	
149435	Throttle operating link rod assembly	X25	42	K
149623	Cover, extension		51	A
149636	Filter, petrol		55	K,O
149648	Rubber, mounting		33	
149649	Bracket assembly, L.H.		27	K
149650	Bracket assembly, R.H.		27	K
149698	Tube, distance, L.H.S.		40	K
149699	Hose		12	Z
149753	Wiper arm, L.H.S.		63	K
149759	Wiper blade, L.H.S.		63	K
149772	Hose		53	
149842	Clip, filter		55	K
149843	Connector, top		55	K
149844	Connector, bottom		55	K
149963	Washer		23	
149967	Lead, extension		70	G,GA,K
150011	Switch		47	
150037	Lead, H.T. No. 3		18	A,Z
150039	Engine lead assembly, No. 4 & 5		18	K,O,Z
150051	Lead, coil to distributor		18	A,G,O
150277	Horn push assembly	AH1	60	K,O
150378	Windscreen wiper and washer switch (2 speed)		73	K
150380	Lighting and instrument illumination master switch assembly		73	K
150381	Hazard warning light switch		73	K
150385	Fuel gauge		72	
150386	Temperature gauge		72	
150531	Gasket, sealing block		2	A,GA,K,O,Z
150547	Lead, No. 1		18	
150548	Lead, No. 2		18	
150549	Lead, No. 3 and 4		18	
150693	Nameplate, heater switch		74, 102	
150843	Temperature transmitter		72	A,E,GA,O
150844	Pad, fixing, rubber		64	GA,K
150846	Strap and sleeve assembly		64	GA,K
150911	Tube, P.V.C., black		99	
150921	Gear, 3rd speed		23	
151134	Block, sealing front		2	A,GA,K,O,Z
151191	Shim, L.H.		51	A
151192	Shim, R.H.		51	A

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
151219	Wheelbox assembly		63, 64	
151444	Emission control valve		12	GA,Z
151872	Side marker assembly, front (Amber)		67	K
151873	Side marker assembly, rear (Red)		68	K
151910	Side and flasher direction indicator lamp assembly, front		67	
151956	Wiper arm, L.H.	AJS17	64	K
151957	Wiper arm, R.H.	AJS16	64	K
151958	Wiper blade	AJS18	64	K
151959	Wiper arm, L.H.		63	
151966	Pivot bracket assembly, R.H.		37	
151967	Pivot bracket assembly, L.H.		37	
152077	Headlamp convertor mask		66	GA
152231	Front engine mounting	P1	26	
152462	Lead, extension wiper		70	A
152521	Hose		12	
152522	Hose, water		103	
152523	Hose		103	
152525	Hose		103	
152820	Pedal assembly		43	
152823	Bracket assembly		43	
152825	Pedal assembly		43	
153245	Grease, P.B.C		56	
153317	Grease, P.B.C		56	
200535	Starter motor		58	A,B,E,K,O,P
201246	Brake drum, rear	AB40	52	A,P
201311	Timing cover assembly	B26	6	A,B,P,Z
201316	Housing	C3	9	A,B,E,E-2 litre,K,O,P,Z
201329	Pulley, fan	C14	9	A,B,P,Z
201344	Rear engine plate	A39	3	
201350	Gear, ring	B12	6	A,B,C,E,E-2 litre,K,O,P
201403	Belt, fan	C31	9	A,B,E,O,P,Z
202465	Pulley	B7	6	A,B,P
204226	Rear hub (Inner) assembly	T59	35	A,E,E-2 litre,K
204679	Mainshaft	M1	23	A,B,E,P
204741	Clip, horn assembly	AH3	60	A,E,K,L,Z
205677	Tool kit, complete		56	A
206175	Slave cylinder boss	L8	20	A,B,P
206262	Front damper	R52	31	A
206685	Lower wishbone, R.H.		30	A,E,E-2 litre,K
206686	Lower wishbone, L.H.	R30	30	A,E,E-2 litre,K
207093	Anti-roll bar	S1	32	A,E,K
208058	Rack, steering	W23	40	A,E,K
208142	Mainshaft	BF2	23, 134	E
208493	Petrol pump, complete		13	A,P,Z
208532	Stop, tail lamp		68	K
208715	Friction disc	AB13	51	A,E
208935	Bracket, R.H.	Q19	27	A,E,K
208943	Mounting assembly	Q23	27	A,E,K
209018	Platform, rear engine mounting	P14	26	E,K
209033	Spring, road		31	A
209331	Bracket	Q20	27	A,E,K
209398	Outrigger assembly, R.H.	Q11	27	K
209399	Outrigger assembly, L.H.	Q12	27	K
209423	Bearing assembly	AV39	99	A,E,K,L,P
209438	Crossmember	Q5	27	K
209439	Gusset	Q6	27	K
209440	Gusset	Q7	27	K
209465	Bracket, L.H.	Q16	27	K
209466	Bracket, R.H.	Q15	27	K

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
209542	Tank unit	AE6	55	
209590	Gearbox extension	L29	21	A,E,E-2 litre,K
209656	Control box	AM4	70	Z
209688	Steering column, lower	W5	40	K
209749	Stay assembly, R.H.		53	
209750	Stay assembly, L.H.	AC8	53	
209754	Pipe, L.H.S.		47	K
209755	Pipe, R.H.S.	Z1	47	K
209776	Pipe	E27	12	
209778	Pipe		16	
209836	Bracket and clutch pedal, L.H.S.		43	K
209837	Brake pedal mounting assembly		43	K
209865	Cradle assembly	AC4	53	
209936	Axle casing	T1	33	
210449	Clutch housing, cast iron	L5	20	A
210508	Propellor shaft	V1	39	
210601	Rear crossmember and axle mounting bracket assembly		27	
210862	Rocker cover assembly	A91	5	
210926/M	Scissor jack assembly		56	A,E,K,Z
210926/MH	Handle		56	A,E,K,Z
210926/P	Scissor jack assembly		56	A,E,K,Z
210926/PH	Handle		56	A,E,K,Z
210985	Propellor shaft	BE50	39, 135	
211048	Tie rod lever, R.H.		30	A
211049	Tie rod lever, L.H.	R27	30	A
211124	Washer	A44	3	A
211126	Gasket	B28	6	A,C,E,E-2 litre,K,O,Z
211399	Pipe assembly	Z26	48	A,E,K
211544	Plate	T4	33	A,E
211794	Cooler, oil		145	
211869	Spring, road		31	
211921	Dynamo		58	L,Z
211962	Alternator, 11AC, positive earth		139	K,O
212006	Oil sump assembly	A42	3	
212135	Fan belt	BJ14	140	A,O
212147	Front cover assembly	H5	17	
212164	Camshaft	B16	6	
212294	Gasket	A64	4	
212323	Accelerator pedal assembly, R.H.S.	X1	42	
212344	Road wheel, wire	V10	39	K
212358	Accelerator pedal assembly, L.H.S.	X16	42	
212416	Pipe	E28	12, 101, 103	
212622	Oil seal housing, rear	A28	2	
212721	Fan assembly	C26	9	
212762	Revolution counter	AN4	72	E-2 litre
212766	Washer, joint	A36	3	
212769	Front engine mounting plate assembly	A35	3	
213028	Camshaft		6	
213032	Clutch disengaging lever	L19	20	
213121	Alternator, 11AC, negative earth		139	K,O
213680	Shield, dust, R.H.		51	
213681	Shield, dust, L.H.	AB16	51	
213689	Brake master cylinder (Tandem) assembly, L.H.S.		46	
213946	Rear brake assembly, R.H.		51	
213947	Rear brake assembly, L.H.		51	
214081	Clutch cover assembly		19	
214086	Speedometer, mile	AN1	72	
214087	Speedometer, kilo		72	

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
214088	Distributor assembly		57	
214097	Plate rack assembly	H1	17	
214098	Air cleaner and silencer assembly		17	
214101	Front exhaust pipe assembly	AD1	54	
214144	Spring, road, front	R51	31	
214150	Rear damper and road spring		31	
214176	Pipe assembly, front		47	K
214303	Belt, fan		9	A,O,Z
214521	Towing attachment kit, rear		144	K
214684	Rear axle centre assembly		33	
214799	Distributor assembly		57	
214810	Road wheel		39	
214999	Valve assembly		47	
215098	Speedometer, mile		72	
215099	Speedometer, kilo		72	
215100	Revolution counter		72	
215350	Washer, joint		3	A,GA,K,O,Z
215372	Front engine plate assembly		3	A
215398	Front damper		31	A,K
215421	Pulley, crankshaft		6	
215539	Plate		33	
215735	Light unit		65	A,GA
215758	Motor and gearbox (2 speed)		62	
215789	Front damper and road spring assembly		31	
216066	Brake pedal and mounting bracket assembly		43	
216067	Clutch pedal and mounting bracket assembly		43	
303709	Gearbox case	L1	20	A,B,E,P
304982	Differential casing	T12	33	A,E,P
305137	Adaptor, gearbox	BF3	134	E,E-2 litre,K
305746	Bracket assembly	Q27	28	
305747	Bracket assembly	Q28	28	
305764	Pipe assembly	Z18	48	A,E,K
305765	Pipe assembly, R.H.	Z9	47	A,E
305778	Casing, differential		33	
305824	Petrol pipe	AE17	55	
305894	Spring, road, rear		37	
305894/M	Leaf, main		37	
305911	Pipe assembly	Z20	48	K
305931	Rack and pinion, L.H.S.		40	A,E
305932	Rack and pinion, R.H.S.		40	A,E
305933	Petrol tank	AE1	55	
305936	Pipe assembly, L.H.S.		48	
305937	Pipe assembly	Z33	48	
305946	Pipe assembly		13, 16	
305953	Pipe assembly	AE13	55	
306152	Extension, top cover	N1	25	K
306553	Overdrive unit	BF7	134, 136	E
306603	Vertical link, R.H.		29	A
306604	Vertical link, L.H.	R10	29	A
306677	Rear transverse road spring assembly		37	
306677/M	Leaf, main		37	
307004	Cylinder block assembly	A1	1	
307027	Rear transverse road spring assembly		37	
307027/M	Leaf, main		37	
307245	Wood rimmed steering wheel		142	E,L
307274	Main harness, R.H.S.		141	
307401	Road wheel	V7	39	K
307422	Crankshaft	B1	6	Z

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
307583	Wheel trim		143, 39	X,O
307652	Main harness, L.H.S.		141	
307756	Steering wheel	W1	40	
307869	Intermediate silencer and exhaust pipe assembly	AD11	54	K
307987	Front suspension unit, R.H.		29	
307988	Front suspension unit, L.H.		29	
308086	Manifold, exhaust	E1	12	
308087	Manifold, inlet	E3	12	
308111	Main harness, R.H.S.		70	
308112	Main harness, L.H.S.		70	
308123	Rear silencer and tail pipe assembly	AD29	54	
308159	Pipe assembly		47	K
308263	Skid plate assembly		28	K
308412	Main harness, L.H.S.		70	
308885	Main harness		70	
402611	Chassis frame, complete		27	
402619	Radiator block assembly	AC1	53	
402823	Radiator block assembly		53	
500047	Circlip, on spindle	C10	9	E-2 litre,J,K,L,M,O,R,T,V,Y
500057	Washer, lock	BB57	114, 117	
500098	Greaser		41	B,J,L,P,R,T,V,Y,Z
500172	Washer, plain	AV27	98	K,L
500186	Circlip	AA10	49	A,E,J,K,L,P,T,Y
500292	Diaphragm assembly	F11	13	A,E,M,P,Z
500293	Link	F18	13	A,B,P,Z
500309	Washer, plain		98	A,E,K,T
500381	Washer, plain	AC19	53	A,Z
500412	Pin, mills		137	
500464	Washer, copper	L16	20	A,B,E,E-2 litre,J,K,L,P,R,T,V,Y
500469	Washer	A13	2, 4	
500492	Glass	AL45	69	A,E,K,L
500568	Washer	BG14	136	E,E-2 litre,J,K,L,O,P,R,T,Y
500591	Plunger	BG16	136	E,E-2 litre,J,L,O,P,R,T,Y
500594	'O' ring	BG9	136	
500613	Washer	BG67	137	E,E-2 litre,J,L,O,P,R,T,Y
500633	Spring	BG21	136	E,E-2 litre,J,K,L,O,P,R,T,Y
500642	Washer	BG51	137	E,E-2 litre,J,K,L,O,P,R,T,Y
500872	Circlip	M6	23	A,B,E,E-2 litre,K,P
500892	Pinion and sleeve	AG27	58	A,B,E,E-2 litre,K,P
500926	Bush	AG17	58	A,B,E,K,O,P
500927	Bush	AG13	58	A,C,E,O,P
500974	Pin, mills	B54	8	A,E,E-2 litre,K,O,P
501128	Spring, diaphragm	F12	13	A,B,P,Z
501258	Washer	A53	3	
501362	Window	AL31	69	K,L,P
501436	Bulb	AL44	69	A,E,E-2 litre,K,L,P,V,Y,Z
501606	Pin, mills		138	E,E-2 litre,K
501651	"Wellseal", jointing compound		4	
501704	Cap	AG26	58	A,B,E,K,O,P
501705	Brush set	AG23	58	A,B,E,K,O,P
501706	Bracket assembly	AG16	58	A,B,E,K,O,P
501708	Spring set	AG18	58	A,B,E,K,O,P
501709	Nut	AG30	58	A,B,E,K,O,P
501710	Spring, main	AG29	58	A,B,E,K,O,P
501711	Spring, pinion, retaining	AG28	58	A,B,E,K,O,P
501712	Bracket assembly	AG12	58	A,B,E,K,O,P
501714	Armature assembly	AG15	58	A,B,E,K,O,P
501715	Coil	AG14	58	A,B,C,E,K,O,P
501795	Washer	AY40	88, 89, 107	L,P,T

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
501823	Interior, bulbholder		68	B,C,K,L,V
502136	Washer	W18	40	A,E,K,O,P,Z
502146	Washer	AM11	71, 135	E,E-2 litre,K,L,O,T,Y
502148	Wire		40	A,E,K,P,T,Y,Z
502210	Bolt	AG24	58	A,B,E,K,O,P
502245	Spring	F17	13	L,M,V
502248	Washer	F14	13	A,B,P,Z
502249	Washer	F13	13	A,B,P,Z
502264	Cover	AL32	69	A,K,L
502287	Bulb	AL5	68	A,E,K,L,M,O,P,V,Y,Z
502379	Bulb	AK22	67, 68	A,E,E-2 litre,K,M,O,P,V,Y,Z
502452	Washer, plain	AV31	98, 106	O
502459	Wing mirror		142	A,E,O,P,R,T,Y
502559	Cage, free wheel	BG54	137	E,E-2 litre,J,K,L,O,P,R,T,Y
502560	Breather	BG101	138	E-2 litre,J,K,L,P,R,T,Y
502650	Nipple, spoke		39	K,L,R
503213	Sleeve		48, 70	A,K,L,O,V,Y
503438	Washer, lock	AU24	93, 198	C,L,Y
503594	Cover and bearing		62	A,B,L,P,R,T,V
503603	Sundry parts set		62	A,B,L,P,R,T,V,Y
503604	Crosshead and rack		63, 64	B,C,GA,K,T,V,Y,Z
503627	Nut		98, 101, 103, 106	A,C,E,E-2 litre,M,O,P,Y
503959	Screw	G24	14	L,T
503969	Screw	G32	15	L,P
504603/O	Cable, outer, L.H.S.		135	A,K,P,T,Y
504603/I	Cable, inner, L.H.S.		135	A,K,P,T,Y
504617/I	Cable, inner	BF48	135	L,R
504617/O	Cable, outer	BF48	135	L,R
504621/I	Cable, inner, R.H.S.		135	E,K,O,P
504621/O	Cable, outer, R.H.S.		135	E,K,O,P
504806	Sleeve		65, 66	A,E,K,L,P,Y
504863	Spring and rotor assembly	D2	11	A,B,P
504877	Shoe, hold down spring	AB36	52	A,B,E,E-2 litre,K,P,R,Z
504878	Cup, washer	AB37	52	A,B,E,E-2 litre,K,P,R,Z
504948/O	Cable, outer, L.H.S.		72	
504948/I	Cable, inner, L.H.S.		72	
505237	Gasket	F4	13	A,B,P,Z
505239	Valve assembly	F7	13	A,B,E,E-2 litre,K,L,M,O,P,T,V,Y,Z
505240	Retainer	F8	13	A,B,E,E-2 litre,K,M,O,P,T,V,Y,Z
505241	Gasket	F9	13	A,B,E,E-2 litre,K,M,O,P,T,V,Y,Z
505259	Washer, lock		113	A,E,T,GA
505260	Washer, lock		106	A,B,E,E-2 litre,O,T,Y
505307	Washer, lock	AV30	98, 101, 102, 103, 104	E-2 litre,K,L,O,P
505543	Head, filter cover	F1	13	
505552	Nut	AU25	93	
505627	Washer	AU23	93	
505771	Nut	AV29	98, 101, 103, 115	
505825	Bezel		142	A,E,O,P,R,T,Y
505869	Sundry parts set		62	A,G,K,L,O,P
505883	Body, rubber	AL25	68	K,L,M,P,R,V,Y
505884	Rim	AL21	68	K,L,M,P,R,V,Y
505886	Lens	AL22	68	
506044	Sunwheel assembly	BG57	137	E,E-2 litre,K,P
506063	Rollers, steel	BG65	137	E
506064	Operating valve lever assembly	BG8	136	
506066	Bearing	BG86	138	E,E-2 litre,K,P
506067	Speedometer driving gear assembly	BG85	138	E,E-2 litre,K,P

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
506070	Spring	BG15	136	E,E-2 litre,K,L,O,P
506071	Screw	BG91	138	E,E-2 litre,K,L,O,P
506076	Screw	BG25	136	E,E-2 litre,K,P
506081	Bearing housing	BG47	137	E,E-2 litre,K,P
506082	Stud	BG2	136	E,E-2 litre,K,P
506083	Stud	BG3	136	E,E-2 litre,K,P
506084	Piece	BG53	137	E,E-2 litre,K,P
506091	Ring	BG58	137	E,E-2 litre,K,P
506097	Plate	BG40	136	E,E-2 litre,K,P
506098	Washer	BG41	136	E,E-2 litre,K,P
506099	Speedometer driving gear	BG93	138	E,E-2 litre,K,P
506101	Joint		136	E,E-2 litre,K
506103	Stud	BG5	136	E,E-2 litre,K,P
506104	Plate	BG48	137	E,E-2 litre,K,P
506105	Stud	BG4	136	E,E-2 litre,K,P
506107	Plate	BG37	136	E,K,P
506108	Washer	BG92	138	E,E-2 litre,K,O,P
506109	Plate	BG78	138	E,E-2 litre,K,P
506111	Bearing	BG72	137	E,E-2 litre,K,P
506112	Bearing	BG46	137	E,E-2 litre,K,P
506113	Bearing	BG70	137	E,E-2 litre,K,P
506114	Plug	BG38	136	E,E-2 litre,K,P
506115	'O' ring	BG88	138	E,E-2 litre,K,P
506117	Plug	BG13	136	E,E-2 litre,K,L,O,P
506118	Washer	BG28	136	E,E-2 litre,K,P
506119	Gear	BG87	138	E,E-2 litre,K,P
506129	'O' ring	BG31	136	E,E-2 litre,K,P
506130	'O' ring	BG56	137	E,E-2 litre,K,P
506157	Nut		25	A,E,K,O,Z
506423	Service kit		13, 56	
506542	Circlip	Y4	43	A,C,E,E-2 litre,K,O
506751	Washer, shakeproof		115	G,GA
507086	Screw	AK4	65, 66	A,K,L,M,R,V,Y,Z
507153	Arm, rocker	F19	13	A,M,P,V,Z
507158	Pin	F22	13	A,M,P,V,Z
507159	Retainer	F23	13	A,M,V,Z
507223/I	Cable, inner	AN9	72	A,K,L
507223/O	Cable, outer	AN10	72	A,K,L
507865	Wheel cylinder kit		51, 56	A,B,P,V
508007	Circlip	G22	14	A,L
508017	Screw	G29	15	A,L
508137	Shade	AN16	73	
508138	Window	AN15	73	
508139	Holder, bulb	AN17	73	
508165	Bulbholder and plate	AL24	68	B,J,K,L,M
508169	Gear, brush	AJ2	62	A,E,K,L,M,O,V,Y
508170	Brush set	AJ3	62	A,E,K,L,M,O,V,Y
508182	Crosshead and rack	AJ11	63	A,E,K,L
508194	Screw, set		130	A,K,O
508229	Steering wheel		40	
508250	Screw, self tapping		97	A,E,Z
508445	Service kit, master cylinder		44, 56	A,E,E-2 litre,K
508725	Clip, cable		70	A,E,O
508726	Clip, cable		105	A,E,G,K,L,Y
508762	Nut		67, 68	K,Y
508875	Washer, plain	AH8	60, 86, 89, 90, 91, 115, 135	E,E-2 litre,K
508955	Water pump repair kit		8, 56	A,E,K,P,Z
508978	Circlip	B50	7, 8	A,C,E,E-2 litre,K,O,P
509108	Washer, carburettor linkage	G57, G63	16	

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
509141	Screw, set		121	A,B,O
509161	Screw, self tapping		96	A
509199	Screw		115	G,Y
509210	Screw	BB66	115	A,E,L,O,Z
509260	Bush	R58	31	A,E,E-2 litre,K,Y,Z
509279	Screw, self tapping		120, 121	A,E,L,Y
509302	Brush set	AG9	58	A,E,L,M,O,P,T,V,Y,Z
509303	Bracket	AG6	58	A,L,P,T,V,Y,Z
509304	Bush	AG7	58	A,E,K,L,M,O,P,T,V,Y,Z
509305	Oiler assembly	AG8	58	A,E,K,L,M,O,P,T,V,Y,Z
509306	Spring	AG10	58	A,E,K,L,M,O,P,T,V,Y,Z
509307	Bearing	AG2	58, 139	A,E,K,L,M,O,P,T,V,Y,Z
509308	Bracket	AG1	58	A,E,L,M,O,P,T,V,Y,Z
509309	Nut, shaft	AG3	58, 139	A,E,K,L,M,O,P,T,V,Y,Z
509310	Washer, spring		139	A,E,K,O
509311	Armature assembly	AG5	58	A,L,P,T,V,Y,Z
509316	Bolt	AG11	58	A,E,L,M,O,P,T,V,Y,Z
509317	Sundry parts set		58	A,E,K,L,O,P,T,V,Y,Z
509361	Spanner		56	A,E,K
509374	Field coil	AG4	58	A,L,P,V,Y,Z
509481	Housing bearing assembly (Reconditioned unit)		9	Z
509537	Circlip	W31	41	A,E,K,L,O,Z
509539	Plug, screwed	T60	35	E,E-2 litre,K,L
509556	Screw, self tapping		94/5/7	A,G,K,Y
509563	Washer		114, 115	A,E,GA
509651	Synchro operating sleeve assembly	M23	23	A,E-2 litre,K,L,P
509652	Gear and sleeve assembly	M8	23	A,B,P
509736	Nut, dome	AL33	69	A,K,L
509761	Washer, plain		106	A
509815	Hypoid housing	T7	33	A,E
509817	Bracket assembly	AG19	58	A,C,E,K,O,P
509818	Bush	AG20	58	A,C,E,K,O,P
509819	Spring set	AG22	58	A,C,E,K,O,P
509820	Sleeve	AG21	58	A,C,E,K,O,P
509860	Bolt, wedglok	L15	20	E-2 litre,K
510005	Crown wheel and pinion	T15	33	A,E
510065	Washer, plain	AU22	93	C,L,Y
510125	Screw, self tapping	AU35	94	E,K,L
510127	Washer, plain		67, 68	A,E,K,M,O
510218	Bulb, 12 volt		65	A,E,K,L,M,O,R,T,Y,Z
510219	Bulb, 12 volt		66	A,E,K,L,M,O,R,Y,Z
510249	Circlip	K13	19	Z
510273	Screw	AV41	99	A,K
510289	Washer, plain		117, 120	
510293	Screw, set		84	A,E,K
510369	Nut	AN20	73	A,C,E,K,O,Z
510396	Nut	AN25	73	
510397	Washer	BB44	113, 117	A,O
510408	Pin, cotter		33	A,E,E-2 litre,K,L,O
510451	Sealing ring	D8	11	A,Z
510503	Screw, set	AH7	60, 106	E,K,L
510524	Washer, plain	BB58	114, 117	
510527	Seal, on piston	K11	19	E,V
510561	Nut	T58	35	A
510618	Nut, nyloc	T79	36	A,E,E-2 litre,K,P,Z
510650	Body and primer assembly	F15	13	A,P,Z
510651	Priming handle set	F16	13	A,P,Z
510814	Spring, plunger	Y51	44	L,Y
510857	Screw, self tapping	AU29	94	K,L

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
510892	Light unit		54	K,L,V
510893	Spring		65, 66	A,K,L,M,V,Z
510894	Adaptor and cable assembly	AK6	65, 66	V
510930	Oil pump, complete (Reconditioned unit)		11	
510940	Cover, dust	Y35	44	E,E-2 litre,K
510985	Motor and gearbox		62	L
511000	Shaft and gear assembly		62	L
511001	Bolt, fixing	AJ8	62	A,C,E,K,L,M,O,V,Y
511002	Cover, end	AJ1	62	A,C,E,L,Y
511003	Armature	AJ6	62	A,C,E,K,L,M,V,Y
511004	Coil, field	AJ5	62	A,E,L,Y
511005	Stud		62	A,C,E,K,L,M,V,Y
511006	Switch, parking	AJ10	62	C,E,K,L,M,O,Y
511007	Shaft and gear assembly		62	L
511031	Pin	AB7	51	A,E,Z
511032	Clip	AB8	51	A,E,Z
511034	Service kit		56	
511044	Washer	BC21	117	L
511096	Rod, connecting	AJ9	62	A,E,K,L,Y
511138	Seal, gland	YA3	46	E,K,L,Z
511170	Screw, set		113	
511194	Washer	AY28	107	L
511195	Washer	AY37	107	L
511243	Service manual		56	
511290	Pinion and barrel		58	K,O
511345	Clip	AM13	71, 135	E,E-2 litre,K
511384	Screw		94, 95	G,K
511479	Screw, set	AV22	98, 117, 120	E,O
511481	Lead, starter to solenoid		71	
511485	Lead, engine to body		71	
511541	Sleeve		70	K
511551	Sleeve		70	K
511568	Rivet		87	
511585	Cover	AM5	70	E,E-2 litre,K,M,O,Z
511586	Resistance	AM6	70	E,E-2 litre,K,M,O,Z
511587	Resistance	AM7	70	E,E-2 litre,K,M,O,Z
511664	Screw	AV34	98	K
511670	Screw	AWS40	103	G,L
511705	Carburettor throttle spindle	G3	14	
511706	Carburettor throttle disc	G4	14	
511709	Lever	G9	14	L
511710	Nut	G10	14	L
511711	Washer, tab	G11	14	L
511712	Screw	G39	15	
511713	Carburettor piston lift pin	G20	14	
511714	Rear carburettor pick-up lever assembly	G13	14	
511715	Front carburettor pick-up lever assembly		14	
511716	Spring, return	G15	14	L
511717	Spring, return		14	L
511718	Carburettor cam lever, front		14	
511719	Carburettor cam lever, rear	G17	14	
511720	Carburettor lever return spring		14	
511721	Carburettor cam return spring	G12	14	
511722	Washer	G16	14	L
511723	Bolt	G19	14	L
511724	Tube, for pivot bolt	G14	14	L
511725	Carburettor spring washer	G18	14	
511726	Screw	G7	14	
511727	Bearing, jet	G30	15	L
511728	Screw	G34	15	L

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
511729	Washer	G31	15	L
511730	Spring	G33	15	L
511731	Pipe	G35	15	
511732	Pipe		15	
511737	Float chamber	G40	15	
511738	Gasket	G50	15	L
511739	Float chamber		15	
511740	Grommet	G44	15	
511741	Bolt	G41	15	
511743	Mounting rubber	G43	15	L
511744	Washer, steel	G42	15	L
511745	Washer	G45	15	
511749	Lever assembly	G54	16	L
511750	Lever assembly	G55	16	L
511765	Screw, set		102, 104	K
511771	Washer	G36	15	
511772	Washer, brass	G37	15	L
511773	Nut	G38	15	L
511786	Screw	BA20	111	E
511790	Rear axle centre assembly		33	
511800	Lens	AL1	68	K
511801	Screw	AL2	68	K,O
511802	Gasket	AL3	68	K
511803	Gasket	AL6	68	K
511836	Cap, distributor	AF1	57	
511837	Rotor	AF2	57	E,E-2 litre,K
511838	Contact set	AF3	57	E,E-2 litre,K
511839	Stud	AF4	57	E,E-2 litre,K
511841	Nut	AF6	57	E,E-2 litre,K
511842	Screw	AF7	57	E,E-2 litre,K
511844	Screw	AF9	57	E,E-2 litre,K
511846	Lead, earth	AF11	57	E,E-2 litre,K
511847	Plate	AF13	57	E,E-2 litre,K
511851	Wick	AF15	57	E,E-2 litre,K
511856	Washer	AF18	57	E,E-2 litre,K
511857	Clip	AF21	57	E,E-2 litre,K
511859	Gear	AF23	57	E,E-2 litre,K
511860	Washer	AF24	57	E,E-2 litre,K
511861	Plug	AF25	57	E,E-2 litre,K
511863	Ring	AF30	57	E,E-2 litre,K
511864	Washer	AF31	57	E,E-2 litre,K
511865	Pin, coupling	AF33	57	E,E-2 litre,K
511866	Coupling	AF32	57	E,E-2 litre,K
511930	Screw	AV25	98	K
512106	Washer	AV26	98	K
512114	Solenoid	BG75	138	E,E-2 litre,K
512135	Screw, set	BC24	117	
512156	Screw, self tapping		94, 95	G,K,O,Z
512222	Gasket	AK10	65, 66	K,L,M
512223	Headlamp assembly		65	K,L,M
512224	Headlamp assembly		65	K,L,M
512231	Light unit	AK2	65	A,K,L,M,Z
512241	Light unit		65, 66	A,K,L,M,Z
512244	Headlamp assembly		66	A,K,L
512419	Gaiter assembly	R6	29	A,E,E-2 litre,K
512420	Gaiter assembly	W49	41	A,E-2 litre,K
512461	Screw, set		94	G,K,O,Z
512462	Screw, set		85	K,L
512488	Top cover extension and handle assembly		25	

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
512539	Pad, lining		51	A,E
512544	Cap, dust	AB10	51	E,Z
512611	Washer, chrome		111	G,O
512632	Needle and seat assembly	G48	15	L
512633	Float and lever assembly	G46	15	L
512646	Rod	G49	15	A
512767	Overdrive kit, R.H.S.		134	
512768	Overdrive		134	
512781	Wire	W47	41	K,L
512800	Retainer, spring	Y44	44	M
512801	Stem valve	Y40	44	M
512802	Seal, valve	Y39	44, 46	M
512803	Washer, spring	Y42	44, 46	M
512955	Blade, rubber	AJ22	63	
512987	Plate	AK3	65, 66	A,K,L,O
513063	Screw, bleed	K16	19	Z
513192	Valve body assembly	BG24	136	E
513193	Relief valve kit		136	E
513194	Planet carrier assembly	BG61	137	E
513195	Annulus assembly	BG69	137	E,E-2 litre,K
513196	Oil pump plunger assembly	BG20	136	E,E-2 litre,K
513197	Front casing assembly	BG1	136	
513198	Rear casing assembly	BG95	138	E,E-2 litre,K
513199	Spring	BG52	137	E,E-2 litre,K
513200	Clutch sliding member assembly	BG44	137	E,E-2 litre,K
513201	Washer	BG82	138	E,E-2 litre,K,O
513202	Oil filter	BG35	136	E,E-2 litre,K
513203	Bolt	BG49	137	E,E-2 litre,K
513204	Washer	BG79	138	E,E-2 litre,K
513205	Magnet set	BG36	136	E,E-2 litre,K,L,O
513206	Plug	BG27	136	E,E-2 litre,K
513207	Spring	BG26	136	E,E-2 litre,K
513208	Spring	BG66	137	E,E-2 litre,K,O
513209	Freewheel inner member	BG62	137	E,E-2 litre,K
513210	Spring	BG63	137	E,E-2 litre,K
513211	Tube	BG94	138	E,E-2 litre,K
513212	Coupling, flange	BG97	138	E
513214/1	Adjustment washer	BG74	137	E,E-2 litre,K
513214/2	Adjustment washer	BG74	137	E,E-2 litre,K
513214/3	Adjustment washer	BG74	137	E-2 litre,K
513214/4	Adjustment washer	BG74	137	E,E-2 litre,K
513215	Plate	BG68	137	E,E-2 litre,K
513216	Cam	BG17	136	E,K
513218	Valve	BG11	136	E,K
513219	Spring	BG55	137	E,E-2 litre,K
513220	Piston	BG54	137	E,E-2 litre,K
513222	Body	BG22	136	E,E-2 litre,K
513223	Spring	BG59	137	E,E-2 litre,K
513224	Bearing, needle roller		137	E,E-2 litre,K,L
513225	Screw, set	BG83	138	E,E-2 litre,K,L,O
513226	Screw, set	BG80	138	E,E-2 litre,K,O
513227	Nut	BG50	137	E,E-2 litre,K
513228	Ring	BG45	137	E,E-2 litre,K
513229	Bearing	BG73	137	E,E-2 litre,K
513231	Oil seal	BG96	138	E,E-2 litre,K
513265	Rim	AK5	65, 66	K,L,M,Z
513266	Spring	AK7	65, 66	K,L,M,Z
513267	Screw	AK9	65, 66	K,L,M,Z
513414	Rear axle centre assembly		33	
513800	Package unit	T55, V2	35, 39	E-2 litre,K,O

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
513854	Special oil, rear axle		56	O
513961	Motor and gearbox		62	
513962	Shaft and gear assembly	AJ7	62	K
513971	Ring		145	
514023	Sleeve		58	K,O
514024	Cup, shaft		58	K,O
514025	Bushing and bearing		58	K,O
514026	Armature assembly		58	K,O
514064	Washer	AK16	67	E-2 litre,K,L,Z
514066	Interior bulbholder		68	K,L
514067	Grommet	AL14	68	K,L
514082	Engine oil cooler kit		145	
514088	Motor		101	
514106	Pop-out unit		145	O
514124	Battery, dry (Alternative to 515189)		70	Z
514200	Adjusting screw and locknut assembly		138	E,E-2 litre,K
514438	Washer, plain		85	K,Z
514517	Wire wheel kit		39	E,K
514518	Wire wheel kit		39	E,K
514578	Light unit		66	K,L
514579	Headlamp assembly		66	K,L
514580	Fluid, brake		42	K
514600	Power stop vacuum servo kit		144	
514639	Special grease axle shaft		56	O
514648	Heater kit		101	
514698	Rivet, shouldered	K4	19	
514713	Rivet	K7	19	Z
514714	Plate, pressure	K5	19	Z
514715	Clip, retaining	K6	19	O,Z
514717	Cover and straps	K1	19	Z
514912	Water pump assembly		9	Z
514930	Spoke, short		39	Z
514931	Spoke, long		39	K
514940	Bracket		145	
514981	Spring, switch		62	A,O
515002	Clip		70	O,Z
515045	Rim, unit seating		64	A,Z
515060	Grommet	AK23	67	Z
515061	Grommet	AK24	67	Z
515147	Spring	AB6	51	Z
515148	Spring		51	Z
515149	Screw, bleed	AB9	51	A,Z
515150	Service kit	AB4	51	A,Z
515181	Plunger cylinder	Y45	44	Z
515182	Plunger cylinder	Y46	44	Z
515189	Battery dry (Alternative to 514124)		70	
515218	Plate, retaining light bulb		65	A,Z
515225	Cable, pin assembly	AN39	16, 74	
515258	Service kit, brake master cylinder		44, 56	
515277	Facing package		19	
515279	Screw, set		98	K
515290	Rack and pinion assembly, L.H.S.		40	
515291	Rack and pinion assembly, R.H.S.		40	
515297	Service kit, slave cylinder		19, 56	
515298	Cover, dust, over end of body	K14	19	
515299	Retainer, dust cover	K15	19	
515328	Screw, set		85	K,Z
515356	Circlip	BG60	137	
515448	Fuel pipe link filter		143	O,Z
515591	Plate, retaining drive end bearing	BH5	139	A,E,K,O
515592	Circlip	BH6	139	A,E,G,K,O

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
515593	'O' ring	BH3	139	A,E,G,K,O
515653	Light unit		54	K,Z
515659	Headlamp assembly		54	K
515710	Washer, lock	AF5	57	E-2 litre,K
515711	Lead, L.T. with grommet	AF10	57	E-2 litre,K
515747	Cylinder head assembly		3	Z
515748	Cylinder head assembly (Low compression)		4	
515789	Nut, locking	AN36	74	
515870	Brake shoe assembly	AB34	52	
515873	Lead battery positive to solenoid		71	
515900	Front suspension unit, L.H.		29	
515901	Front suspension unit, R.H.		29	
515975	Eversure spot lamp, sealed beam		101	
515976	Eversure fog lamp, sealed beam		101	
515977	Ball joint		101	
515978	Ball joint		101	
515993	Carburettor assembly, front	G1	14	
515994	Carburettor assembly, rear		14	
515997	Lead battery negative, L.H.S.		71	
515999	Lead battery negative, R.H.S.		71	
516029	Engine unit, high compression		1	
516029R	Engine unit, high compression (Reconditioned unit)		1	
516030	Engine unit, low compression		1	
516030R	Engine unit, low compression (Reconditioned unit)		1	
516031	Gasket set installation		1, 56	
516032	Cylinder head assembly (High compression)		3	
516033	Cylinder head assembly	A54	4	
516034	Gasket set, decarbonising		1, 56	
516035	Gasket set, engine		1, 56	
516042	Bolt	BH20	139	A,E,K,O
516043	Bracket	BH1	139	A,E,K,O
516044	Washer	BH2	139	A,E,K,O
516045	Rotor	BH7	139	A,E,K,O
516046	Bracket	BH11	139	A,E,K,O
516047	Bearing, needle roller	BH12	139	A,E,K,O
516048	Bearing	BH13	139	A,E,K,O
516049	Heatsink		139	E,K,O
516050	Heatsink		139	E,K,O
516051	Brush, spring	BH17	139	A,E,K,O
516052	Brush box	BH16	139	A,E,K,O
516053	Connector	BH18	139	A,E,K,O
516054	Screw	BH14	139	A,E,K,O
516055	Washer, insulating	BH15	139	A,E,K,O
516056	Stator	BH8	139	A,E,K,O
516057	Sundry parts set	BH19	139	A,E,K,O
516059	Heatsink	BH10	139	A,E,K,O
516060	Heatsink	BH9	139	A,E,K,O
516064	Lead, starter to solenoid, R.H.S.		71	
516079	Rod connecting and lever assembly	G59	16	
516080	Top cover assembly		21	
516086	Needle jet	G25	14	
516089	Damper assembly	G27	14	
516158	Setscrew	BB43	113	
516161	Gearbox assembly		20	
516162	Gearbox assembly		26, 135	
516168	Gearbox assembly		20	
516169	Gearbox assembly		20, 135	

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
516212	Piston	AB2	51	A
516213	Spring, diaphragm	K2	19	
516214	Ring, diaphragm	K3	19	
516218	Cap, filler reservoir	Y58	44	
516219	Reservoir	Y55	44	
516221	Washer, plain	Y56	44	
516222	Nut, jam	Y57	44	
516223	Spring plunger	Y43	44	
516224	Circlip, push rod retaining	Y48	44, 46	
516225	Rod push assembly	Y47	44	
516226	Cover, dust, cylinder end	Y49	44	
516227	Service kit, brake master cylinder		44, 56	
516237	Condenser	AF8	57	
516238	Mainshaft and cam assembly	AF16	57	
516239	Spring set	AF17	57	
516240	Vacuum control assembly	AF19	57	
516241	Lever throttle return, rear	G6	14	
516242	Lever throttle return, front		14	
516245	Suction chamber assembly	G23	14	
516246	Lid	G49	15	
516247	Lid		15	
516248	Continental touring kit		142	
516257	'P' clip		48	GA
516278	Spot lamp		143	A,E,K
516279	Fog lamp		143	A,E,K
516288	Screw, set		98	K
516301	Lens, amber	AL10	68	
516302	Lens, red	AL10	68	
516303	Screw	AL11	68	
516304	Rim	AK14	67	
516305	Screw, rim fixing	AK15	67	
516306	Lens, flasher, amber	AK18	67	
516307	Lens, flasher, white	AK18	67	
516308	Lens, sidelamp	AK17	67	
516309	Lens, sidelamp	AK17	67	
516506	Cover, fuse box		70	K
516507	Coil and ignition lead kit		18	
516543	Tow rope and luggage rack strap		146	E,K,O
516591	Nut		59	A,E,G,K,O
516592	Washer, lock		59	A,E,G,K,O
516614	Nut		48	E,G,K,O
516626	Needle, jet		14	
516653	Rear axle centre assembly		33	A
516665	Kit, emission control valve		12	G,K,O,Z
516675	"Plugmaster", sparking plug spanner		146	K
516676	"Levermaster", wheel brace		146	K
516762	Woodscrew		98	K,GA
516770	Glove, steering wheel, brown leather		144	K,O
516771	Glove, steering wheel, simulated brown leather		144	K,O
516815	Washer, plain		93	G
516817	Axle casing assembly		33	
516819	Carburettor assembly, front		14	
516820	Carburettor assembly, rear		14	
516821	Washer		15	
516835	Bolt		15	
516856	Mainshaft and cam assembly		57	
516857	Spring set		57	
517020	Cover, dust	YA28	46	

# NUMERICAL INDEX

Part No.:	Description	Plate No.	Page	Also Used on Models
517021	Plunger, primary	YA2	46	
517022	Plunger, secondary	YA6	46	
517023	Seal, ring	YA7	46	
517028	Spring	YA4	46	G,K
517029	Stem, valve	YA5	46	G,K
517030	Retainer, spring	YA8	46	G,K
517031	Spring	YA9	46	G,K
517032	Spacer	YA11	46	G,K
517033	Tipping valve assembly	YA13	46	G,K
517034	Valve seat	YA14	46	G,K
517035	Spring, valve	YA15	46	G,K
517036	Circlip	YA16	46	G,K
517037	Nut, valve	YA17	46	G,K
517038	Seal	YA18	46	G,K
517039	Reservoir, fluid assembly	YA19	46	G,K
517040	Cap, filler	YA20	46	G,K
517041	Baffle	YA21	46	G,K
517042	Gasket	YA22	46	G,K
517043	Seal	YA23	46	G,K
517044	Screw, set	YA24	46	G,K
517045	Washer, spring	YA25	46	G,K
517046	Push rod assembly	YA27	46	K
517050	Insulator		57	K
517059	Cylinder head assembly		3	
517145	Screw, set		90	G,K
517148	Screw		89	G,K
517150	Screw, set		90	G,K
517200	Spring, fixing		65	A
517201	Retainer		65	A
517263	Washer		117	G
517264	Washer, lock		117	G
517312	Coil and engine leads set		18	A
517333	Service kit		46	G,K
517352	Coil and ignition lead kit		18	
517436	Contact set		57	X,K
517582	Emission control valve kit		12	E,GA,K,Z
517617	Top cover extension and hand lever assembly		25	
517620	Blade, rubber		63	K
517621	Windscreen wiper motor (2 speed)		63	GA,K
517632	Fluid, clutch and brake		48, 56	E,K
517633	Fluid, clutch and brake		48, 56, 146	E,GA,K
517634	Fluid, clutch and brake		48, 56, 146	E,GA,K
517643	Armature	AJS2	64	GA,K
517644	Brush assembly	AJS3	64	GA,K
517645	Switch, parking	AJS4	64	GA,K
517646	Gear assembly, R.H.S.	AJS5	64	GA,K
517678	Screw, set		91	GA
517679	Screw		89, 90, 91	GA,O
517681	Screw, set		88, 89	GA
517682	Screw, set		87, 88	GA,O
517685	Screw, set		90	GA
517687	Screw, set		89, 90	GA
517691	Washer, spacer		87, 88	GA
517692	Washer, plain		87, 88	
517696	Cable, inner		74	
517697	Cable, inner		74	
517700	Service kit		46	
517841	Headlamp assembly		65	GA
518145	Lens, sidelamp, amber	AK17	67	

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
518218	Bulb		62	A
545017	Owners handbook, English		56	
545018	Owners handbook, French		56	
545019	Owners handbook, German		56	
545028	Owners handbook, Flemish		56	
545031	Owners handbook, Danish		56	
545073	Owners handbook, U.S.A.		56	
550924	Washer, waved	AT60	90	A,E,K,L,O,Z
552075	Pin, hinge		106	L
552218	P.V.C. moulding	AZ2	108	L,R
552522	Rivet, pop		110	
553121	Clip, seal to hinge pillar	AT81	91	C,K,L,T,Y
553252	Button	BD6	118, 119	A,C,E,K,P,T,Y,Z
554021	Stud	BD10	118	K,O,T,Y,Z
554264	Touch-in paint, signal red		143	
554407	Rivet, imex	BB73	111, 115	D,E,L,O,V,Y
554449	Fire extinguisher		145	A,E,O,P,T,Y
554517	Socket	BD5	118, 119	A,C,E,K,L,O,P,T,Y,Z
556141	Rivet		80	A,B,D,E,L,K,V,Z
557046	Locking barrel with key	AY31	106	A,B,E,L
557493	Wing mirror, Desmo 169		142	K
557922	Rivet, imex	AX13	118, 133	A,E,K,L,O
559980	Screw		101, 103, 104	A,E,K,L,O,P,Y,Z
560632	Exterior driving mirror 'D' type		142	O,R
561210	Rivet, imex	BA22	111, 118	A,E,K,L,O,Z
561335	Zip fastener		110	A,L
561785	Ring, hog	BE16	126	E-2 litre,O,Y
562116	Bonnet lock kit		142	A,E
562403	Rivet, pop	AC18	53	A
563032	Plate, back		97	K,L
563769	Rivet, imex	BD9	118	A,E,K,L,O,Z
565313	Eyelet	BA6	110	L
565747	Button	BB49	114	K,L
565749	Eyelet dot	BB51	114	L
565750	Stud, hood retainer	BB52	114	
565756	Cap, tubular	BA7	97, 110	E,K,L
566298	Demister panel		145	A,L,O
567642	Socket	BB50	114	K
568445	'B' post trim, L.H. (Red)	BD32	119	
568446	'B' post trim, R.H. (Red)	BD31	119	
568476	Spare wheel cover	AY56	107	
568497	'A' post upper finisher trim, L.H.		119	
568498	'A' post upper finisher trim, R.H.	BD30	119	
568515	Rivet, imex	BA9	110, 115	L,M
568528	Finisher, L.H. (Blue)	BD32	119	
568529	Finisher, R.H. (Blue)	BD31	119	
568808	Pad	BD38	121	
569033	Luggage grid		142	
569116	Cigarette lighter		145	
569121	Carpet, front floor (Black) L.H., L.H.S.	BD2	118	
569126	Carpet, front floor (Black) L.H., R.H.S.		118	
569131	Carpet, front floor (Black) R.H., L.H.S.	BD1	118	
569136	Carpet, front floor (Black) R.H., R.H.S.		118	
569156	Carpet, gearbox cover (Black) L.H.S.	BD16	119	
569161	Carpet, gearbox cover (Black) R.H.S.	BD15	119	
569254	Button	BD3	118	K,L,O
569286	Touch-in paint (Conifer Green)		143	L,O,Z
569521	Touch-in paint (White)		143	L,O,Z
569527	Touch-in paint (Wedgwood Blue)		143	L,O,Z
569557	Touch-in paint (Cherry Red)		143	O,Z

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
569563	Engine bay valance kit		86	
569924	Valance assembly, L.H.	AS56	86	
569925	Valance assembly, R.H.	AS55	86	
569939	Barrel		73	O,Z
570023	Hard top assembly		116	
570145	Nut, spire		94, 95	G,GA,K,O
570147	Front floor mat, L.H. (Black) L.H.S.		118	
570148	Mat, front floor (Black) L.H., L.H.S.		118	
570152	Front floor mat, L.H. (Black) R.H.S.		118	
570153	Mat, front floor (Black) L.H., R.H.S.		118	
570157	Front floor mat, R.H. (Black) L.H.S.		118	
570158	Mat, front floor (Black) R.H., L.H.S.		118	
570162	Front floor mat, R.H. (Black) R.H.S.		118	
570163	Mat, front floor (Black) R.H., R.H.S.		118	
570409	Wing mirror (Wingard)		142	O
570938	Carpet, gearbox cover (Black)		119	
571086	Petrol locking filler cap		144	
571201	Spring	AT68	91	K,L
571228	Touch-in paint (Royal Blue)		143	O,Z
571276	Touch-in paint (Conifer Green/Acrylic)		143	O,Z
571286	Push button	AT67	91	K,L
571287	Screw, set		91	K,L
571288	Washer, shakeproof		91	K,L
571289	Screw, set	AT69	91	K,L
571295	Cover assembly, L.H., front seat squab, leathercloth (Red)	BE4	124	
571296	Cover assembly, L.H., front seat squab, leatherette (Midnight Blue)	BE4	124	
571298	Cover assembly, L.H., front seat squab, leathercloth (Black)		124	
571299	Cover assembly, squab, leathercloth, L.H. (Light Tan)	BE4	124	
571300	Cover assembly, squab, leathercloth, L.H. (S/Blue)	BE4	124	
571305	Cover assembly, L.H., front seat squab, leather (Red)	BE4	125	
571306	Cover assembly, L.H., front seat squab, leather (Midnight Blue)	BE4	125	
571308	Cover assembly, L.H., front seat squab, leather (Black)	BE4	125	
571309	Cover assembly, squab, leather, L.H. (Light Tan)	BE4	125	
571310	Cover assembly, squab, leather, L.H. (Shadow Blue)	BE4	125	
571315	Cover assembly, R.H., front seat squab, leathercloth (Red)		124	
571316	Cover assembly, R.H., front seat squab, leathercloth (Midnight Blue)		124	
571318	Cover assembly, R.H., front seat squab, leathercloth (Black)		124	
571319	Cover assembly, squab, leathercloth, R.H. (Light Tan)		124	
571320	Cover assembly, squab, leathercloth, R.H. (Shadow Blue)		124	
571325	Cover assembly, R.H., front seat squab, leather (Red)		124	
571326	Cover assembly, R.H., front seat squab, leather (Midnight Blue)		125	
571328	Cover assembly, R.H., front seat squab, leather (Black)		125	

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
571329	Cover assembly, squab, leather, R.H. (Light Tan)		125	
571330	Cover assembly, squab, leather, R.H. (Shadow Blue)		125	
571467	Cover spare wheel		106	
572540	Barrel, ignition locking	AN23	73	K,L
572560	'B' post trim	BD32	119	
572561	'B' post trim	BD31	119	
572653	Foam cushion border	BE13	125	
573096	Mud flap kit		145	
573349	Wing mirror, Desmo 166		142	K
573461	Wing mirror		142	K,O,Z
573476	Luggage grid		142	
573647	Cover assembly, leathercloth (Red)	BE14	125	
573648	Cover assembly, leathercloth (Midnight Blue)	BE14	125	
573649	Cover assembly, leathercloth (Black)	BE14	125	
573650	Cover assembly, front seat cushion, leathercloth (Red)		125	
573651	Cover assembly, front seat cushion, leathercloth (Shadow Blue)		125	
573657	Cover assembly, leather (Red)	BE14	126	
573658	Cover assembly, leather (Midnight Blue)	BE14	126	
573659	Cover assembly, leather (Black)	BE14	126	
573660	Cover assembly, front seat cushion, leather (Light Tan)	BE14	126	
573661	Cover assembly, front seat cushion, leather (Shadow Blue)	BE14	126	
573677	Wing mirror speed		142	
573900	Diaphragm, seat base	CN5	128	K
574172	Front seat cushion pack, leathercloth (Red)		125	
574173	Front seat cushion pack, leather (Midnight Blue)		125	
574174	Front seat cushion pack, leathercloth (Black)		125	
574175	Front seat cushion pack, leather (Red)		125	
574176	Front seat cushion pack, leather (Midnight Blue)		125	
574177	Front seat cushion pack, leather (Black)		125	
574245	Body mounting details pack		77	
574369	Backlight hood	BB46	114	
574370	Quarterlight hood	BB47	114	
574386	Strap, retainer, header rail	BB48	114	
574400	Trunk lid assembly	AY1	106	
574405	Tonneau cover kit (Black) L.H.S.		110	
574406	Tonneau cover kit (Black) R.H.S.		110	
574407	Tonneau cover kit (White) L.H.S.		110	
574408	Tonneau cover kit (White) R.H.S.		110	
574411	Hard top to soft top conversion kit (Black)		144	
574412	Hard top to soft top conversion kit (White)		144	
574413	Hard top kit (White headlining)		116	
574422	Cover, wheelarch (Red) L.H.	BD34	120	
574423	Cover, wheelarch (Midnight Blue) L.H.	BD34	120	
574424	Cover, wheelarch (Black) L.H.	BD34	120	
574425	Cover, wheelarch (Light Tan) L.H.	BD34	120	

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
574426	Cover, wheelarch (Shadow Blue) L.H.	BD34	120	
574427	Cover, wheelarch (Red) R.H.	BD33	120	
574428	Cover, wheelarch (Midnight Blue) R.H.	BD33	120	
574429	Cover, wheelarch (Black) R.H.	BD33	120	
574430	Cover, wheelarch (Light Tan) R.H.		120	
574431	Cover, wheelarch (Shadow Blue) R.H.	BD33	120	
574437	Rivet, imex	BB60	114, 120	
574485	Body complete, painted and trimmed, R.H.S.		75	
574485HT	Body complete, hard top, painted and trimmed (Including seats) R.H.S.		75	
574514	Body shell, prime finish, R.H.S.		76	
574515	Body shell, prime finish, L.H.S.		76	
574518	Body shell, prime finish, R.H.S.		76	
574519	Body shell, prime finish, L.H.S.		76	
574541	Body complete, painted and trimmed, L.H.S.		75	
574541HT	Body complete, hard top, painted and trimmed (Including seats) L.H.S.		75	
574542	Eyelet, sail	BD43	122	
574543	'B' ring, sail eyelet	BD44	122	
574544	Eyelet, sail	BD45	122	
574545	'B' ring, sail eyelet	BD46	122	
574579	Extension kit		142	K,O
574580	Replacement flat glass lens for 573461 and 573349		142	K,O
574586	Wing mirror, Magnatex 09 convex		142	K,O
574593	Finisher, trim, 'B' post, L.H. (Light Tan)	BD31	119	
574594	Finisher, trim, 'B' post, R.H. (Light Tan)	BD32	119	
574626	Touch-in paint details (Valencia Blue)		143	A,E,G,K,O
574637	Pack, front seat cushion, leather (Red)		125	
574638	Pack, front seat cushion, leathercloth (Light Tan)		125	
574722	Emergency windscreen		144	K
574761	Single gauge instrument mounting panel		146	K
574762	Double gauge instrument mounting panel		146	K
574862	Wing mirror, Desmo 166		142	K,O
574863	Wing mirror, Desmo 168		142	K,O
574885	Touch-in paint details (Jasmine Yellow)		143	O
574890	Safety warning triangle		146	K
574929	Pack, front seat cushion, leathercloth (Shadow Blue)		125	
574984	Hood, sewn assembly (Black)		114	
574985	Hood, sewn assembly (White)		114	
575016	Carpet, front floor (Black) L.H., L.H.S.		118	
575017	Carpet, front floor (Black) L.H., R.H.S.		118	
575018	Carpet, front floor (Black) R.H., L.H.S.		118	
575019	Carpet, front floor (Black) R.H., R.H.S.		118	
575118	Hard top to soft top conversion kit (Black)		144	
575119	Hard top to soft top conversion kit (White)		144	
575141	Hard top kit (White headlining)		116	
575144	Bolt, "Longlok"		94, 95	K,GA
575180	Cover, moquette		115	
575194	Touch-in paint (Damson)		143	GA,K,O

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
575260	Body shell, prime finish, L.H.S., U.S.A. only (Less doors, bonnet, trunk lid and front valance)		76	
575289	Hard top to soft top conversion kit (Black)		144	
575290	Hard top to soft top conversion kit (White)		144	
575318	Strap, retainer		114	
575379	Touch-in paint details (Laurel Green)		143	
575386	Body shell, prime finish, L.H.S., U.S.A. only (Complete with doors, bonnet, trunk lid and front valance)		76	
575387	Body complete, soft top, painted and trimmed (Including seats) L.H.S., U.S.A. only		75	
575388	Body complete, soft top, painted and trimmed (Less seats) L.H.S., U.S.A. only		76	
575435	Roof assembly		116	
575448	Torsion bar, L.H.	BES2	128	
575449	Torsion bar, R.H.		126	
575620	Roof assembly		116	
575621	Hard top kit (Black headlining)		116	
575622	Hard top kit (White headlining)		116	
575624	Body shell, prime finish, L.H.S. (Less doors, bonnet, front valance and trunk lid)		76	
575625	Body shell, prime finish, R.H.S. (Less doors, bonnet, front valance and trunk lid)		76	
575626	Body shell, prime finish, L.H.S. (Complete with doors, bonnet, trunk lid and front valance)		76	
575627	Body shell, prime finish, R.H.S. (Complete with doors, bonnet, trunk lid and front valance)		76	
575680	Door buffer, with reflector (Screw-on type)		146	
575681	Door buffer, with reflector (Self adhesive type)		146	
575696	Body complete, soft top, painted and trimmed (Including seats) R.H.S.		75	
575697	Body complete, hard top, painted and trimmed (Including seats) R.H.S.		75	
575698	Body complete, soft top, painted and trimmed (Including seats) L.H.S.		75	
575699	Body complete, hard top, painted and trimmed (Including seats) L.H.S.		75	
575700	Body complete, hard top, painted and trimmed (Including seats) L.H.S., U.S.A. only		75	
575701	Body complete, soft top, painted and trimmed (Less seats) R.H.S.		75	
575702	Body complete, hard top (Less seats) R.H.S.		75	
575703	Body complete, soft top, painted and trimmed (less seats) L.H.S.		75	

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
575704	Body complete, hard top, painted and trimmed (Less seats) L.H.S.		75	
575705	Body complete, hard top, painted and trimmed (Less seats) L.H.S., U.S.A. only		76	
575802	Finisher, trim, 'B' post, L.H. (Shadow Blue)	BD32	119	
575803	Finisher, trim, 'B' post, R.H. (Shadow Blue)	BD31	119	
575928	Pack, front seat cushion, leather (Shadow Blue)		125	
600032	Retainer	BC4	116	L
600395	Grommet	AE16	55	A,B,E,J,L,P,R,T,Y
600396	Grommet	AN11	72, 133	A,D,J,K,L,M,P,T,V,Y,Z
600398	Plug		133	B,D,J,K,M,O,P,R,T,V,Y,Z
600399	Plug		133	J,K,L,O,P,R,T,Y,Z
600421	Plug, blanking		133	E,K,R
600635	Escutcheon, handle	AY30	106	A,B,L
600832	Pin	AT63	89, 90	A,E,K,L,O,P,T
600949	Washer	AY32	106	A,B,E,L,V
601552	Rod battery fixing		81	P,R
601553	Angle		81	A,E,P
601597	Plate, retaining	AV48	99	A,E,K,P
601678	Knob	AW5	101	B,L,P,V
602637	Hose	AW29	102, 104	
602638	Hose, demister	AW30	102, 104	K
602821	Seal, check arm, front door	AT80	91	A,E,K,Y
603212	Washer	AY11	106	A,E,L,P
603213	Washer	AY8	106	A,E,L,P
603344	Spring		80	A,E,K,L,Z
603382	Spring	AT64	89, 90	A,E,K,P,O
603559	Clip, cable harness		78, 80, 83, 96	A,B,D,E,K,O,T,V,Y,Z
603811	Clip		98, 129	C,K,T,Y
603906	Name plate, overdrive	BF53	135	A,E,P,T,Y
604132	Tubing	AX16	105	
604146	Tubing	AX6	105	A,C,E,K,L,M,O,Y,Z
604917	Trunk lid hinge, R.H.	AY7	106	A,E,L,P
604918	Trunk lid hinge, L.H.		106	A,E,L,P
605953	Sleeve		65, 66, 68	
607506	Grommet	AC30	53	B,D,V
607621	Bracket, mounting		80	K
607628	Bracket		83	K
607637	Plate, mounting bracket		80	K
607663	Bonnet catch assembly	AS47	85	A,E,K
607664	Catch plate	AS48	85	A,E,K
607711	Plate, backing	AS29	84	A,E,K
607823	Pin, door hinge	AT3	87	A,E,K,Z
607824	Hinge, door, assembly	AT2	87	A,E,K
607863	Bracket assembly mounting	AQ20	78	A,E
607867	Stud	AT38	89	A,E,L
607869	Bracket, anchor	AS28	83	A,E,K
607902	Washer	AG39	89	
608135	Support		99	K
608136	Channel		99	A,E,K,L
608139	Insulator		99	K
608183	Cover, harness		99	

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
608185	Support bracket clamp	AV65	100	A,E,K,L
608222	Felt strip	AV66	100	A,E,K,L
608223	Felt strip	AV67	100	A,E,K,L
608297	Buffer, rubber	BE29	126	D,E
608307	Clip, locating	BC10	116	A,E,K,L
608316	Plunger	AX8	105	A,E,K,Z
608319	Container	AX1	105	A,E,F,L,Y,Z
608356	Cable slip ring	AV38	99	A,K,L
608380	Badge assembly	AS37	69	A,E,K
608383	Plate, retaining		79	A,E,K,L
608454	Front door remote control handle	AT62	90	A,E,K,L,O,P
608462	Slip ring and insulator	AV37	99	A,E,K,L
608467/WL	Wing mirror (Wingard)		142	O
608511	Clip	AT85	92	A,E,K,L,O,Z
608516	Clip, long		92, 131	A,E,E-2 litre,K,O,Z
608520	Clip	AN11	84	A,E,K,O
608522	Clip, trim cover to facia panel		96	A,E,L,Z
608563	Seal, rear	AQ25	79	A,E,K
608604	Clip	AT13	87	A,E,K,L,O,Z
608605	Washer	BB67	115	A,E,L
608643	Packing	AS26	83, 106	A,E,K,R
608703	Clip	AT61	90	A,E,K,L,O,Z
608756	Seal, gearbox cover top and sides	AQ26	78	A
608815	Plate		78	A,E
608817	Clip, trim		130, 131, 132	A,E,E-2 litre,GA,K,L,M,O,Z
608854	Washer	AZ32	108, 109	A
609123	Trunnion		101, 103, 104	A,E,K,L,Y,Z
609157	Bracket	AX12	105	A,V
609206	Bracket, listing rail mounting		116	A
609269	Clip		99	
609331	Head catch	BB65	115	A,L
609332	Head catch assembly	BB70	115	A,L
609526	Spacer	AX11	105	C,E,K,L,Z
609629	Clip		99	K
609639	Spring	AV58	100	A,E,K,L
609649	Washer, sealing rubber	AT44	89	A,K,L
609792	Bezel	BF32	135	C,E,E-2 litre,K,L,O
609793	Bezel	AN22	73	C,E,K,L
609795	Bezel	AN42	60, 74, 101	E,K,L
609919	Bezel	AX10	105	C,E,K,L
609931	Plate, tapping	AS49	85	A,K
609933	Bezel	AN27	73	L
609946	Knob, screen washer	AX9	105	A,C,E,L,V
609964	Spring, catch rod, L.H.	BE25	126	K
609965	Spring, catch rod, R.H.		126	K
609966	Knob	BE24	126	K
610042	Washer	AT9	87	A,F,K
610181	Demister outlet		102	L
610520	Clip, trim, squab cover to frame	BE6	120, 125, 126, 129, 132	A,E,E-2 litre,K,L,M,O,Z
610573	Clip	AN31	73	B,E,K,V
610624	Stud	BA21	111, 118	A,E,K,L,O
610675	Rubber, sealing	AS37	84	K,L
610676	Seal	AS52	85	K
610685	Bezel	AN30	73	E,Y
611011	Label, instruction, L.H.S.		61	G,K,L
611012	Label, instruction, R.H.S.		61	G,K,L
611096	Budget lock	AY18	106	L
611135	Plate, catch, assembly	AY23	106	L
611177	Washer, rubber	N37	25	A,E,E-2 litre,K,O

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
611364	Steering column cowl assembly	AV37	99	A,E,K
611367	Clamp, steering column, lower half	AV57	100	A,E
611368	Clamp, upper half	AV57	100	A,E,K
611369	Cover harness assembly	AV43	99	A,E,K,L
611399	Label, instruction, L.H.S.		61	A,K
611400	Label, instruction, R.H.S.		61	A,K
611437	Cover	BC14	93, 117	A,E,K,L,Z
611443	Seal	AY41	107	
611611	Finisher (Black)	BC39	117	
611639	Bolt	BC19	117	L
611640	Bolt, hex., domed	BB56	93, 114	
611641	Bolt, hex.	BC33	117	
611665	Reinforcement		81	K
611669	Cover, screen	AV20	93	L
611793	Clip, cable, horn leads to radiator cradle		70	
611822	Pad, rubber	AQ28	79	K,L
611895	Bracket		93	L
611938	Plate, cover	BF28	134	E,E-2 litre,K
611952	Steering column cowl assembly, L.H.S.		99	A,K
611974	Escutcheon	BF31	135	E-2 litre,K
612261	Hook, diaphragm	BES5	128	A,E,E-2 litre,G,K,L,M,O,Z
612297	Reinforcement assembly		78	K
612301	Plug		133	K
612306	Wing mirror		133, 142	A,C,K,O,P,Y
612473	Sliding stay	AY34	107	L
612474	Bolt	AY36	107	L,M
612475	Screw	AY35	107	L
612527	Mounting bracket, L.H.	AQ3	78	K
612528	Mounting bracket, R.H.		78	K
612577	Angle		78	K
612601	'T' piece	AX15	105	A,C,E,K,L,O,V,Y,Z
612616	Bracket, bonnet location	AR5	80	K
612617	Plate, locating	AR6	80	K
612659	Support, L.H.	AS23	83	
612660	Support, R.H.		83	K
612704	Bracket	AV52	100	
612792	Sealing strip	AT10	87	
612806	Weatherstrip, waist	AT12	87	
612825	Bracket		96	
612829	Bracket, L.H.	AS53	85	K
612830	Bracket, R.H.		85	K
612850	Plate, support		80	K
612873	Bracket, reinforcement, L.H.	AS18	83	K
612874	Bracket, reinforcement, R.H.		83	K
612900	Bracket	AV61	100	K
612938	Angle	AQ22	78	K
612962	Peg, bonnet location	AS9	83	
612970	Tube	AR13	81	K
612976	Plug	BA24	111	
612981	Gusset, pedals, L.H.	AR11	80	K
612982	Gusset, pedals, R.H.		80	K
613017	Handle	AT40	89	A,E,K,L,O
613024	Check arm	AT79	91	K
613025	Grommet	AR14	81	K
613045	Link assembly, upper	AS34	84	K
613049	Stop bolt	AT20	87	
613051	Rod, battery fixing		81	Z
613076	Clamp assembly		83	K
613093	Plinth	AL49	69	E,K,L

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
613097	Cover plate, demister		102	K
613110	Seal	AL50	69	K,L
613155	Rubber		81	K
613169	Clip	AT11	87	K
613178	Block, mounting	AP8	77	
613186	Ashtray	AV4	96	K
613239	Rivet		91	K
613314	Bezel	AW25	101	A,E,K
613326	Spacing block	AT17	87	
613344	Bracket assembly	AQ10	78	K
613347	Rear seat pan assembly	AQ11	78	
613350	Bracket assembly, L.H.		80	K
613351	Bracket assembly, R.H.		80	K
613358	Bracket assembly, petrol tank support, L.H.		78	
613359	Bracket assembly, petrol tank support, R.H.	AQ17	78	
613362	Footrest, gearbox, R.H.S. only	AQ27	79	
613378	Glass, stop	AT45	89	K
613417	Strip, glazing	AT21	87	
613420	Tacking piece, seat squab	BE5	125	
613435	Hook assembly, seat retention	BE18	126	
613466	Pad, sealing	AV49	99	K
613474	Washer		85	K
613478	Bracket, support		78	K
613483	Hose, water	AW17	101	
613485	Hose	AW16	101	
613493	Bracket	AW13	101, 103	
613502	Trunk lid handle assembly	AY29	106	
613506	Cap, petrol	AE9	55	K,L
613508	Tube, distance piece	BC22	117	L
613524	Rear side lamp filler plate assy., L.H.	AR29	82	
613525	Rear side lamp filler plate assy., R.H.	AR28	82	
613579	Support bracket, petrol tank casing		78, 81	
613595	Cover plate	AV32	98	
613597	Closing panel assembly, grille aperture to wheelarch	AS22	83	
613598	Closing panel assembly, grille aperture to wheelarch	AS21	83	
613599	Spacer, tube	AV6	96	K
613600	Clip		98	C,K
613607	Ring	N34	25	K
613648	Seal	AW3	101, 103	K
613650	Jet mounting assembly	AX17	105	K,V
613656	Tubing	AJ17	63	K
613666	Seal, rear	AS35	84	K
613685	Gusset	AR10	80	K
613686	Gusset, dash	AR9	80	K
613687	Gusset, dash	AR8	80	K
613704	Plate, protection, trunk lid rear valance	AY28	106	
613751	Link assembly	AS33	84	K
613766	Clip	BA15	111	
613769	Clip, trim	BES33	131	GA,K,L
613770	Clip, trim	BF30	121, 131	K,L
613812	Cover	AQ13	78	K,L
613859	Reinforcement		106	
613871	Interior mirror assembly	AV28	K,L	
613886	Clip		111	
613927	Retainer	BC2	116	

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
613928	Plate, tapped	BC3	116	
613931	Plate, tapped	BC38	117	
613941	'D' washer	AW7	96, 101, 103	K
613950	Listing rod, front	BC7	116	
613951	Listing rod, centre	BC8	116	
613952	Listing rod, rear	BC9	116	
613954	Moulding, finisher	AU5	93	K,L
613955	Finisher	BC13	117	A,K,L
613966	Hook, diaphragm, short	BES4	128	K,L,M,O,Z
614005	Washer, rubber	BC37	117	
614006	Bush, friction	AY49	84, 107	E,E-2 litre,K,L,O,Z
614030	Weatherseal	BC17	117	
614053	Finisher	BC36	117	
614081	Grommet		118	
614084	Grommet		118	
614114	Bracket	AV21	98	
614118	Hose	AW15	101	K
614122	Steering column cowl assembly, R.H.S.		99	A,E,K
614125	Seal	AW2	101, 103	K
614126	Clip	AX2	105	K
614150	Pad, sealing	BC18	117	
614599	Plate	AV33	98	
615691	Finisher	BA19	111	
615692	Finisher	BA18	111	
615695	Bracket, mounting, L.H.		86	
615696	Bracket, mounting, R.H.		86	
615698	Bracket		86	
615699	Washer, plate		86	
615706	Bracket		80, 86	K
615707	Clip		48	A,E,K,O,Z
615810	Reinforcement		78	K
615811	Clip	BF38	135	
615829	Washer	AW31	108	Z
615980	Plate assembly	BD25	78, 119	K
616034	Trunnion	AWS45	104	K,O
616048	Washer, P.V.C.		73	A,E,K
616187	Rubber, sealing		115	L
616196	Plasti-rivet		82	
616206	Drain flap	AW36	102, 104	E,K
616317	Mounting visor centre	AV34	94	L
616318	Mounting visor outer	AV33	94	L
616428	Rubber	BC15	117	
616429	Rubber		117	
616627	Seal	AW4	101, 103	K
616852	Control assembly	AW23	101	
617037	Cover, facia panel (Black)	AV2	96	
617078	Pad, sound deadening self adhesive		87	K
617296	Stud	BA11	110	
617297	Bracket assembly, centre	BA10	110	
617298	Bracket assembly, outer	BA12	110	
617402	Washer, seating, front	AT71	91	K
617403	Washer, seating, rear	AT72	91	K,Z
617870	Plate, mounting		141	A
617992	Bolt		107	
617993	Cap		107	
618177	Sail, eyelet	BA2	110	
618178	Ring	BA3	110	
618241	Pad, cushion front, top	BE10	125	
618274	Retainer, lock striker, L.H.	AR22	81	K
618275	Retainer, lock striker, R.H.		81	K

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
618277	Remote control mechanism and link assembly, L.H.	AT55	90	K
618278	Remote control mechanism and link assembly, R.H.		90	K
618290	Washer, plate		73	K
618342	Striker dovetail assembly, L.H.	AT51	89	K
618343	Striker dovetail assembly, R.H.		89	K
618486	Plate, attachment, L.H.	CA5	97	K
618487	Plate, attachment, R.H.		97	K
618505	Stud plate assembly	CA4	97	K
618789	Rubber, plinth mounting	AL38	69	K
618944	Ferrule, gear lever		119	K,Z
618946	Bezel, clamp		74	A,E,K
619076	Washer, sealing	AT52	89	K
619099	Plate, tapped, lock striker, L.H.	AR21	81	K
619100	Plate, tapped, lock striker, R.H.		81	K
619482	Reinforcement		81	K
619498	Strap assembly, squab	BES8	128	K,O
619499	Strap assembly, squab	CN8	128	K
619500	Strap assembly, squab	BES10	128	K
619501	Strap assembly, squab	BES11	128	K
619509	Guide block and stiffening channel assembly	AT16	87	
619739	Bracket, L.H.	AS2	83	K
619740	Bracket, R.H.		83	K
619812	Insert, ferrule		119	K
619822	Clip, edge	BE15	126	K
620171	Finisher, upper, L.H.		119	K
620711	Carpet, dash side, R.H.	BD13	119	K
620721	Carpet, dash side, L.H.	BD14	119	K
620750	Screw, grub	AWS25	103	K,O
620761	Carpet, formed, heelboard	BD19	119	K
620771	Carpet, sill, L.H.	BD18	119	K
620781	Carpet, sill, R.H.	BD17	119	K
620913	Strip, sealing	AT83	91	
621101	Pad, mounting	AP20	77, 119	K
621112	Plate, reinforcement assembly		78	
621252	Extension	AZ29	108	
621292	Washer, plain		119	
621308	Eyebolt	BD23	119	Z
621332	Bracket, angle		99	
621349	Strap assembly, bottom	BES12	128	
621370	Bolt	BD27	119	
621371	Spacer	BD29	119	
621374	Washer, waved	BD28	119	O,Z
621386	Plate, mounting, hood frame to body, L.H.	BB2	112	
621387	Plate, mounting, hood frame to body, R.H.	BB1	112	
621388	Link, No. 1	BB31	113	
621389	Link, No. 2, L.H.	BB27	113	
621390	Link, No. 2, R.H.	BB26	113	
621391	Link, No. 3	BB21	112	
621394	Link, No. 5, L.H.	BB18	112	
621395	Link, No. 5, R.H.	BB17	112	
621398	Link, rear, No. 7	BB8	112	
621399	Link, No. 8	BB11	112	
621402	Spacer	BB13	112	
621418	Tube, distance	AS31	84	
621419	Spacer	AS32	84	

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
621422	Link, No. 4 assembly, L.H.	BB37	113	
621423	Link, No. 4 assembly, R.H.	BB36	113	
621428	Link, front, No. 6, L.H.	BB5	112	
621429	Link, front, No. 6, R.H.	BB4	112	
621430	Rivet, shouldered	BB32	113	
621433	Bracket, fixing roof to body side	BC23	117	
621434	Tie bar, hard top to body side	BC26	117	
621438	Support, wheelarch to rear deck	AQ18	78	
621465	Rivet, special	BB41	113	
621467	Nameplate, Mk. 3	AY52	107	
621468	Nameplate, Spitfire	AY50	107	
621472	Bracket	AV16	97	
621482	Finisher, flange, rear	BA25	111	
621493	Carpet assembly, rear seat pan	BD20	119	
621510	Spacer		73	A,K
621610	Trim board assembly (Red) L.H.	BD36	120	
621611	Trim board assembly (Red) R.H.	BD35	120	
621612	Trim board assembly (Midnight Blue) L.H.	BD36	120	
621613	Trim board assembly (Midnight Blue) R.H.	BD35	120	
621614	Trim board assembly (Black) L.H.	BD36	120	
621615	Trim board assembly (Black) R.H.	BD35	120	
621616	Trim board assembly, rear quarter, L.H. (Light Tan)	BD36	120	
621617	Trim board assembly, rear quarter, R.H. (Light Tan)	BD35	120	
621618	Trim board assembly, rear quarter, L.H. (Shadow Blue)	BD36	120	
621619	Trim board assembly, rear quarter, R.H. (Shadow Blue)	BD35	120	
621628	Clip, finisher attachment	BA26	111	
621629	Button (White)	BA4	110, 114, 122	
621630	Button (Black)	BA4	110, 114, 122	
621639	Socket	BA5	110, 114, 122	
621640	Stud (Black)	BA8	110, 114, 115, 120	
621641	Stud (White)	BA8	110, 114, 115	
621666	Bonnet top assembly		83	
621704	Base, interior mirror		94	G,K
621705	Retainer		94	G,K
621706	Gusset, L.H., L.H.S.		94	K
621707	Gusset, R.H., L.H.S.		80	K
621714	Plate		90	G,K
621721	Pad, felt, petrol tank, front	AE2	55	
621732	Washer, seating		91	
621733	Clip	AT78	91	
621734	Pin, locking		115	G
621755	Handle assembly, L.H.		115	G
621756	Closing hood, R.H.		115	G
621757	Handle hood closing		115	G
621758	Washer, waved		115	G
621759	Escutcheon		115	G
621760	Plate, L.H.		115	G
621761	Plate, R.H.		115	G
621767	Interior mirror assembly		94	K
621773	Private lock assembly	AT77	91	
621801	Finisher, soft top		111	
621802	Finisher, hard top		111	
621876	Door lock striker dovetail, L.H.		90	G,K

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
621877	Door lock striker dovetail, R.H.		90	G,K
622150	Clip, heater hose		81	K
622220	Bracket assembly, heat vent control mounting		94	K
622222	Plate, switch retainer		97	K
622223	Washer, plate		97	K
622224	Bolt, hex	BES40	103, 132	K
622228	Knob assembly, heater control		103	K
622229	Knob assembly, ventilator control	AWS32	103	K
622230	Plate, retainer		97	K
622235	Spacer	AWS26	103	K
622236	Lever, control, ventilator	AWS31	103	K
622237	Lever, control, water valve	AWS23	103	K
622350	Stem assembly, door mirror		92	G,K
622351	Hood assembly, door mirror		92	G,K
622352	Door mirror, passenger side		92	G,K
622431	Retainer, sun visor	BN38	94	GA,K
622443	Bezel		73	A,K
622682	Nut, spacer		73	A,K
622725	Mounting bracket assembly, steering column clamp, upper, L.H.S.		100	
622743	Roof assembly (White)		116	
622812	Demister outlet capping assembly	AWS50	64	K
622813	Demister, outlet		102	
622884	Cover		93	G
622886	Bolt		93	
622887	Bolt		117	G
623150	Link, No. 4 assembly, L.H.		113	
623151	Link, No. 4 assembly, R.H.		113	
623314	Clip		48	K
623420	Piece, filler	BES7	128	K
623431	Pin, locking		115	G
623434	Catch plate, L.H.		115	G
623435	Plate, catch, R.H.		115	G
623469	Handle assembly, hood closing, L.H.		115	G
623470	Handle assembly, hood closing, R.H.		115	G
623489	Tie bar, steering column to fascia, L.H.S.		99	K
623490	Strip, felt		100	K
623491	Strip, felt		100	K
623796	Bracket assembly		78	K
623877	Clip, diaphragm	BES6	128	K
624193	Cable assembly, heater, screen	AWS41	104	K
624276	Label, "Pull boost"	AWS33	103	K
625511	Tensioner, fly	BES18	129	K
625549	Washer, cup		97	K
625571	Grommet, eyebolt		119	GA,O
625580	Washer, special, rubber		67	K
625607	Container, water		105	A
625644	Carrier assembly		105	
625687	Cable assembly		104	
625803	Bracket assembly		110	
625933	Board padding, outer, L.H.	BES19	129	
625934	Board padding, outer, R.H.		129	
625966	Knob		73	
626063	Support, carrier		105	
626071	Cover assembly, sewn, inner, leathercloth, R.H., L.H. seat (Black) (Black)	BES28	130	

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
626072	Cover assembly, sewn, inner, leathercloth, R.H., L.H. seat (Red)	BES28	130	
626073	Cover assembly, sewn, inner, leathercloth, R.H., L.H. seat (Light Tan)	BES28	130	
626077	Cover assembly, sewn, inner, leathercloth, R.H., L.H. seat (Shadow Blue)	BES28	130	
626081	Cover assembly, sewn, inner leathercloth, R.H., L.H. seat (Black)		130	
626082	Cover assembly, sewn, inner, leathercloth, L.H., R.H. seat (Red)		130	
626083	Cover assembly, sewn, inner, leathercloth, L.H., R.H. seat (Light Tan)		130	
626087	Cover assembly, sewn, inner, leathercloth, L.H., R.H. seat (Shadow Blue)		130	
626091	Cover assembly, sewn, inner, leather, R.H. seat (Black)	BES28	130	
626092	Cover assembly, sewn, leather, R.H., L.H. seat (Red)	BES28	130	
626093	Cover assembly, sewn, leather, R.H., L.H. seat (Light Tan)	BES28	130	
626097	Cover assembly, sewn, leather, R.H., L.H. seat (Shadow Blue)	BES28	130	
626101	Cover assembly, sewn, inner, leather, L.H., R.H. seat (Black)		130	
626102	Cover assembly, sewn, inner, leather, L.H., R.H. seat (Red)		130	
626103	Cover assembly, sewn, inner, leather, L.H., R.H. seat (Light Tan)		130	
626107	Cover assembly, sewn, inner, leather, L.H., R.H. seat (Shadow Blue)		130	
626111	Cover assembly, L.H., L.H. seat (Black)	BES22	129	
626112	Cover assembly, L.H., L.H. seat (Red)	BES22	129	
626113	Cover assembly, L.H., L.H. seat (Light Tan)	BES22	129	
626117	Cover assembly, L.H., L.H. seat (Shadow Blue)	BES22	129	
626121	Cover assembly, R.H., L.H. seat (Black)		129	
626122	Cover assembly, R.H., L.H. seat (Red)		129	
626123	Cover assembly, R.H., L.H. seat (Light Tan)		129	
626127	Cover assembly, R.H., L.H. seat (Shadow Blue)		129	
626131	Cover assembly, L.H., L.H. seat (Black)	BES22	130	
626132	Cover assembly, L.H., L.H. seat (Red)	BES22	129	
626133	Cover assembly, L.H., L.H. seat (Light Tan)	BES22	129	
626137	Cover assembly, L.H., L.H. seat (Shadow Blue)	BES22	130	

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
626141	Cover assembly, R.H., R.H. seat (Black)		130	
626142	Cover assembly, R.H., R.H. seat, (Red)		129	
626143	Cover assembly, R.H., R.H. seat, (Light Tan)		129	
626147	Cover assembly, R.H., R.H. seat, (Shadow Blue)		130	
626363	Eyebolt		119	GA,O
626380	Mounting bracket, rear licence plate		69	
626541	Pad, foam		121	
626601	Trim board assembly, rear quarter, L.H. (Black)		120	
626602	Trim board assembly, rear quarter, L.H. (Red)		120	
626603	Trim board assembly, rear quarter, L.H. (Light Tan)		120	
626607	Trim board assembly, rear quarter, L.H. (Shadow Blue)		120	
626611	Trim board assembly, rear quarter, R.H. (Black)		120	
626612	Trim board assembly, rear quarter, R.H. (Red)		120	
626613	Trim board assembly, rear quarter, R.H. (Light Tan)		120	
626617	Trim board assembly, rear quarter, R.H. (Shadow Blue)		120	
650130	Rubber, sealing	AU19	93	K,L
650247	Grommet	AE10	55	L
650261	Escutcheon	AT41	89, 90	A,E,K,L,O
650279	Connection, rubber	AG11	55	G,L
650313	Packing	AV13	93	L
703862	Letter 'T'	AS38	84, 107	A,B,E,K,L,O,R,Z
703863	Letter 'R'	AS39	84, 107	A,B,E,K,L,O,R,Z
703864	Letter 'I'	AS40	84, 107	A,B,E,K,L,O,R,Z
703865	Letter 'U'	AS41	84, 107	A,B,E,K,L,O,R,Z
703866	Letter 'M'	AS42	84, 107	A,B,E,K,L,O,R,Z
703867	Letter 'P'	AS43	84, 107	A,B,E,K,L,O,R,Z
703868	Letter 'H'	AS44	84, 107	A,B,E,K,L,O,R,Z
704875	Knob, windscreen wiper	AN28	73	A,B,G,L,V
704884	Knob, water valve	AW24	101	A,E,K,L,Z
704885	Knob assembly	AN31	73	L
705789	Grommet		79	A,E
706159	Reinforcement assembly, L.H.	AQ12	78	K
706160	Reinforcement assembly, R.H.		78	K
706288	Panel, lower, L.H.	AR34	82	K
706289	Panel, lower, R.H.		82	K
706311	Panel, filler, L.H.	AS20	83	K
706312	Panel, filler, R.H.	AS19	83	K
706422	Panel, front, L.H.	AR35	82	K
706423	Panel, front, R.H.		82	K
706453	Reinforcement		83	K
706465	Support assembly, bottom pivot, trunk lid stay	AR31	82	
706539	Tube assembly	AS25	83	K
706548	Panel, inner, L.H.	AS15	83	K
706549	Panel, inner, R.H.	AS14	83	K

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
706550	Bracket	AR16	81	K
706556	Joint, finisher	BA14	111	
706569	Crash pad assembly, facia	AV3	96	
706600	Finisher	AR30	82	K
706728	Nozzle, demister	AW28	102	K
706768	Tubing	AJ16	63	K
706771	Panel, R.H.S.	AV72	100	
706772	Panel, L.H.S.		100	
706781	Glass channel, L.H.	AT22	87	
706782	Glass channel, R.H.		87	
706789	Channel, L.H.	AT15	87	
706790	Channel, R.H.		87	
706804	Facia panel, L.H.S.		96	
706805	Facia panel, R.H.S.	AV1	96	
706807	Cover panel	AY55	107	
706832	Felt, front floor, L.H.	BD12	119	
706833	Felt, front floor, R.H.	BD11	119	
706835	Bracket		109	
706843	Air deflector, L.H.	AC17	53	
706844	Air deflector, R.H.	AC16	53	
706919	Grommet, gear control	N33	25	
706920	Trim roll assembly, support bracket	AV28	98	
706934	Valve, water	AW10	101, 103	
707319	Finisher	BA16	111	
707348	Headlining assembly	BC6	116	
707349	Cover, gearbox assembly	AQ23	78	
707931	Door seal	AT82	91	
708092	Base, cushion	BE8	125	
708250	Retainer	BB62	114	L
708288	Sun visor assembly, L.H.	AV32	94	L
708289	Sun visor assembly, R.H.	AV31	94	L
708479	Escutcheon	AV40	99	E,K,L
708633	Handle	AV5	96	K
708750	Finisher, trim door, waist rail, L.H. (Black)	AT87	92	
708751	Finisher, trim door, waist rail, R.H. (Black)		92	
708756	Trim cover, windscreen, L.H.	AV8	93	L
708757	Trim cover, windscreen, R.H.	AV7	93	L
708758	Trim cover, windscreen	AV9	93	L
708759	Trim cover	AV10	93	
709376	Pad, cushion side, top, L.H.	BE12	125	
709377	Pad, cushion side, top, R.H.	BE11	125	
709386	Door handle assembly, outside	AT66	91	K
709387	Channel glass assembly, rear, L.H.	AT23	88	
709388	Channel glass assembly, rear, R.H.		88	
709473	Door trim pad and carpet assembly (Red) L.H.	AT84	91	
709474	Door trim pad and carpet assembly (Midnight Blue) L.H.	AT84	91	
709475	Door trim pad and carpet assembly (Black) L.H.	AT84	91	
709476	Pad and carpet assembly, door trim, L.H. (Light Tan)	AT84	91	
709477	Pad and carpet assembly, door trim, L.H. (Shadow Blue)	AT84	91	
709483	Door trim pad and carpet assembly (Red) R.H.		91	
709484	Door trim pad and carpet assembly (Midnight Blue) R.H.		91	

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
709485	Door trim pad and carpet assembly (Black) R.H.		91	
709486	Pad and carpet assembly, door trim, R.H. (Light Tan)		91	
709487	Pad and carpet assembly, door trim, R.H. (Shadow Blue)		91	
709691	Bracket		96	K
709692	Support assembly, L.H.	AV14	96	K
709693	Support assembly, R.H.	AV13	96	K
709753	Buffer assembly		108	O
709842	Cover plate		98	K
709845	Plinth, number plate lamp	AL37	69	K
710679	Channel	AS1	83	K
710680	Strut, centre	AS3	83	K
710714	Gusset, L.H.	AS4	83	K
710715	Gusset, R.H.		83	K
711985	Angle retaining, hood to rear deck	BB55	114	
712390	Panel, wheelarch, inner assembly, L.H.		78	
712391	Panel, wheelarch, inner assembly, R.H.	AQ15	78	
712536	Grommet and millboard assembly, handbrake		79	
712541	Intermediate hoodstick assembly	BB30	113	
712563	Bar, spring assembly, L.H.	AZ19	108	K
712564	Bar, spring assembly, R.H.	AZ18	108	K
712565	Support, rear bumper, L.H.	AZ24	108	K
712566	Support, rear bumper, R.H.	AZ23	108	K
712567	Bracket support, front valance, L.H.	AS54	85	
712568	Bracket support, front valance, R.H.		85	
712571	Carpet assembly, rear floor (Black)	BD16	119	K
712600	Safety harness	BD22	119	A,F,K
712705	Overrider assembly, front, L.H.	AZ4	108	
712706	Overrider assembly, front, R.H.	AZ3	108	
712726	Bracket hinge assembly, bonnet, lower	AS30	84	
712830	Instrument panel		97	
712877	Trunk floor assembly	AQ19	78	
712907	Knob		74	G,K
712913	Knob		73	A,K
713036	Retainer, centre		114	G
713037	Retainer, outer, L.H.		114	G
713038	Retainer, outer, R.H.		114	G
713201	Header rail		113	G
713491	Button (Black)		110, 114	G,GA
713499	Button (White)		110, 114	G
713501	Socket (Black)		110, 114	G
713511	Stud (White)		114	G
713519	Stud (White)		114	G
713790	Escutcheon, heater controls	AWS39	103	K
714429	Capping		111	GA
714434	Nozzle, demister assembly	AWS54	102, 104	
714460	Pad and carpet assembly, door trim, L.H. (Red)		92	
714461	Pad and carpet assembly, door trim, L.H. (Black)		92	
714462	Pad and carpet assembly, door trim, L.H. (Midnight Blue)		92	
714463	Pad and carpet assembly, door trim, L.H. (Light Tan)		92	
714464	Pad and carpet assembly, door trim, L.H. (Shadow Blue)		92	

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
714470	Pad and carpet assembly, door trim, R.H. (Red)		92	
714471	Pad and carpet assembly, door trim, R.H. (Black)		92	
714472	Pad and carpet assembly, door trim, R.H. (Midnight Blue)		92	
714473	Pad and carpet assembly, door trim, R.H. (Light Tan)		92	
714474	Pad and carpet assembly, door trim, R.H. (Shadow Blue)		92	
714482	Crash pad assembly, facia		96	
714599	Clip	AT78	91	G
714650	Remote control mechanism and link assembly, L.H.		90	K
714651	Remote control mechanism and link assembly, R.H.		90	K
714767	Frame assembly, windscreen		93	
716633	Pad, squab, upper	BES14	128	
716803	Tubing, wheelbox to wheelbox	AJS13	63, 64	K
716967	Tie bar, outer steering column to facia, L.H.S.		99	K
717261	Cover assembly, squab and headrest, sewn, leathercloth, L.H. (Black)	BES16	128	
717262	Cover assembly, squab and headrest, sewn, leathercloth, L.H. (Red)	BES16	128	
717263	Cover assembly, squab and headrest, sewn, leathercloth, L.H. (Light Tan)	BES16	128	
717267	Cover assembly, squab and headrest, sewn, leathercloth, L.H. (Shadow Blue)	BES16	128	
717271	Cover assembly, squab and headrest, sewn, leathercloth, R.H. (Black)		128	
717272	Cover assembly, squab and headrest, sewn, leathercloth, R.H. (Red)		128	
717273	Cover assembly, squab and headrest, sewn, leathercloth, R.H. (Light Tan)		128	
717277	Cover assembly, squab and headrest, sewn, leathercloth, R.H. (Shadow Blue)		128	
717281	Cover assembly, squab and headrest, sewn, leather, L.H. (Black)	BES16	129	
717282	Cover assembly, squab and headrest, sewn, leather, L.H. (Red)	BES16	129	
717283	Cover assembly, squab and headrest, sewn, leather, L.H. (Light Tan)	BES16	129	
717287	Cover assembly, squab and headrest, sewn, leather, L.H. (Shadow Blue)	BES16	129	
717291	Cover assembly, squab and headrest, sewn, leather, R.H. (Black)		129	
717292	Cover assembly, squab and headrest, sewn, leather, R.H. (Red)		129	
717293	Cover assembly, squab and headrest, sewn, leather, R.H. (Light Tan)		129	

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
717297	Cover assembly, squab and headrest, sewn, leather, R.H. (Shadow Blue)		129	
717341	Cover assembly, cushion, leathercloth, L.H. seat (Black)	BES38	131	
717342	Cover assembly, cushion, leathercloth, L.H. seat (Red)	BES38	131	
717343	Cover assembly, cushion, leathercloth, L.H. seat (Light Tan)	BES38	131	
717347	Cover assembly, cushion, leathercloth, L.H. seat (Shadow Blue)	BES38	131	
717351	Cover assembly, cushion, leathercloth, R.H. seat (Black)		131	
717352	Cover assembly, cushion, leathercloth, R.H. seat (Red)		131	
717353	Cover assembly, cushion, leathercloth, R.H. seat (Light Tan)		131	
717357	Cover assembly, cushion, leathercloth, R.H. seat (Shadow Blue)		131	
717361	Cover assembly, cushion, leather, L.H. seat (Black)	BES38	132	
717362	Cover assembly, cushion, leather, L.H. seat (Red)	BES38	131	
717363	Cover assembly, cushion, leather, L.H. seat (Light Tan)	BES38	131	
717367	Cover assembly, cushion, leather, L.H. seat (Shadow Blue)	BES38	132	
717371	Cover assembly, cushion, leather, R.H. seat (Black)		132	
717372	Cover assembly, cushion, leather, R.H. seat (Red)		131	
717373	Cover assembly, cushion, leather, R.H. seat (Light Tan)		131	
717377	Cover assembly, cushion, leather, R.H. seat (Shadow Blue)		132	
717442	Side roll, R.H. side of cushion	BES36	131	
717443	Side roll, L.H. side of cushion	BES37	131	
717451	Headlining assembly (White)		116	
717541	Pad and carpet assembly, door trim, L.H. (Black)		92	
717542	Pad and carpet assembly, door trim, L.H. (Red)		92	
717543	Pad and carpet assembly, door trim, L.H. (Light Tan)		92	
717547	Pad and carpet assembly, door trim, L.H. (Shadow Blue)		92	
717551	Pad and carpet assembly, door trim, R.H. (Black)		92	
717552	Pad and carpet assembly, door trim, R.H. (Red)		92	
717553	Pad and carpet assembly, door trim, R.H. (Light Tan)		92	
717557	Pad and carpet assembly, door trim, R.H. (Shadow Blue)		92	
717601	Cover, spare wheel		107	
717611	Cover, spare wheel		107	
717911	Carpet assembly, L.H.S. (Black)		119	
750157	Support, windscreen	AV12	93	L
750158	Bracket	AV11	93	L
803762	Pad, sound insulation assembly	AQ24	79	A
806144	Rubber, sealing	BC16	117	K,L

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
806634	Panel, L.H.	AQ6	78	K
806635	Panel, R.H.		78	K
806638	Sill panel, inner, L.H.	AQ5	78	K
806639	Sill panel, inner, R.H.	AQ4	78	K
806707	Battery box assembly, R.H.S.	AR12	80	K
806831	Reinforcement	AY2	106	
806866	Droplight glass	AT14	87	
806925	Channel assembly, steering column support, L.H.S.		81	
806926	Channel assembly, steering column support, R.H.S.	AR19	81	
806981	Board assembly, casing petrol tank, rear	BD39	121	
807004	Parcel tray, L.H., R.H.S.	AV12	96	K
807005	Parcel tray, R.H., L.H.S.		96	K
807030	Battery box assembly, L.H.S.		80	K
807036	Window regulator, L.H.	AT31	88	
807037	Window regulator, R.H.		88	
807039	Seat slide assembly, L.H.	BE23	126	
807040	Seat slide assembly	BE22	126	
807072	Parcel tray, R.H., R.H.S.	AV11	96	
807073	Parcel tray, L.H., L.H.S.		96	
807102	Reinforcement assembly, side, front wing, L.H.	AS8	83	K
807103	Reinforcement assembly, side, front wing, R.H.	AS7	83	K
807104	Heelboard, crossmember assembly	AQ9	78	K
807106	Floor assembly	AQ1	78	
807118	Panel assembly, 'A' post and sill reinforcement, L.H.	AR4	80	
807119	Panel assembly, 'A' post and sill reinforcement, R.H.	AR3	80	
807120	Panel assembly, dash front, R.H.S., L.H.		80	
807121	Panel assembly, dash front, R.H.S., R.H.	AR1	80	
807122	Panel assembly, dash front, L.H.S., L.H.		80	
807123	Panel assembly, dash front, L.H.S., R.H.		80	
807379	Panel assembly, front deck	AR18	81	
807499	Backlight glass	BC11	116	
807533	Bracket	AV20	98	
807536	Air box assembly	AR17	81	
808231	Capping		111	
808270	Stoneguard, L.H.	AR83	82	
808271	Stoneguard, R.H.		82	
808355	Rail, header, hood	BB40	113	L
809509	Panel assembly, outer, L.H.	AR20	81	K
809510	Panel assembly, outer, R.H.		81	K
809597	Pad, rubberised assembly, L.H.	BE3	124	
809598	Pad, rubberised assembly, R.H.		124	
809716	Mat, luggage floor	BD21	119	
809747	Airbox assembly		80	K
809786	Channel assembly, L.H.S.		81	K
809918	Parcel tray, L.H.S.		96	K
809922	Pad, cushion assembly	BE9	125	
810291	Door lock assembly, L.H.	AT49	89	K
810292	Door lock assembly, R.H.		89	K
810393	Frame assembly cushion	BE7	125	
810402	Radiator grille assembly	AS50	85	K

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
810451	Front seat assembly, (Midnight Blue) R.H.		123	
810452	Front seat assembly (Midnight Blue) L.H.		123	
810453	Front seat assembly (Black) L.H.		123	
810454	Front seat assembly, trimmed, leathercloth, L.H. (Light Tan)		123	
810455	Front seat assembly, trimmed, leathercloth, L.H. (Shadow Blue)		123	
810461	Front seat assembly (Red) R.H.	BE1	123	
810462	Front seat assembly (Midnight Blue) R.H.	BE1	123	
810463	Front seat assembly (Black) R.H.	BE1	123	
810464	Front seat assembly, trimmed, leathercloth, L.H. (Light Tan)	BE1	123	
810465	Front seat assembly, trimmed, leathercloth, L.H. (Shadow Blue)	BE1	123	
810471	Front seat assembly (Red) L.H.		123	
810472	Front seat assembly (Midnight Blue) L.H.		124	
810473	Front seat assembly (Black) L.H.		124	
810474	Front seat assembly, trimmed, leather, L.H. (Light Tan)		124	
810475	Front seat assembly, trimmed, leather, L.H. (Shadow Blue)		124	
810481	Front seat assembly (Red) R.H.	BE1	123	
810482	Front seat assembly (Midnight Blue) R.H.	BE1	124	
810483	Front seat assembly (Black) R.H.		124	
810484	Front seat assembly, trimmed, leather, R.H. (Light Tan)	BE1	123	
810485	Front seat assembly, trimmed, leather, R.H. (Shadow Blue)	BE1	124	
810631	Pad, squab, lower, L.H. seat	BES13	128	
810632	Pad, squab, lower, R.H. seat		128	
811476	Rear corner bumper assembly, L.H.	AZ17	108	
811477	Rear corner bumper assembly, R.H.		108	
811636	Hoodstick, main assembly	BB3	112	
811638	Hood sewn assembly (Black)	BB45	113	
811639	Hood sewn assembly (White)	BB45	113	
811660	Front bumper bar assembly	AZ1	108	
811676	Front valance assembly		85	
811679	Tube assembly, bonnet hinge, L.H.	AS27	83	
811680	Tube assembly, bonnet hinge, R.H.	AS26	83	
811687	Valance rear panel assembly	AQ21	78	
811688	Panel assembly, rear deck	AR25	81	
811690	Squab board assembly (Red)	BD37	121	
811691	Squab board assembly (Midnight Blue)	BD37	121	
811692	Squab board assembly (Black)	BD37	121	
811693	Squab board assembly, rear compartment (Light Tan)		121	
811694	Squab board assembly, rear compartment (Shadow Blue)		121	
811800	Cover assembly, tonneau (Black) L.H.S.		110	
811801	Cover assembly, tonneau (Black) R.H.S.	BA1	110	
811802	Cover assembly, tonneau (White) L.H.S.		110	
811803	Cover assembly, tonneau (White) R.H.S.	BA1	110	
811830	Hood stowage (Red)	BD40	121	
811831	Hood stowage assembly (Midnight Blue)	BD40	121	
811832	Hood stowage cover assembly (Black)	BD40	122	

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
811833	Hood stowage cover assembly (Light Tan)		121	
811834	Hood stowage cover assembly (Shadow Blue)	BD40	122	
812684	Bracket, mounting, L.H.		94, 95	
812685	Bracket, mounting, R.H.		94, 95	
812711	Sun visor assembly, driver's side (Black)		95	
812741	Sun visor assembly, passenger's side, R.H.S. (Black)		95	
812751	Sun visor assembly, passenger's side, L.H.S. (Black)		95	
812760	Bar, visor mounting, inner		94, 95	
812761	Bar, visor mounting, outer, L.H.		94, 95	
812762	Bar, visor mounting, outer, R.H.		94, 95	
812991	Padding assembly, facia, lower, L.H.S., passengers		98	K
813281	Padding assembly, facia, lower, L.H.S., drivers		98	K
813351	Crash pad assembly, facia		96	K
813365	Panel assembly, outer, L.H.		81	K
813366	Panel assembly, outer, R.H.		81	K
813493	Seat slide assembly, L.H. seat		126	
813494	Seat slide assembly, R.H. seat		126	
813589	Sun visor assembly, driver's side (White)		94	
813619	Sun visor assembly, passenger's side, R.H.S. (White)		94	
813629	Sun visor assembly, passenger's side, L.H.S. (White)		94	
813678	Seat slide assembly, L.H. seat	BES42	132	
813679	Seat slide assembly, R.H. seat		132	
813681	Carpet, sill, L.H.		119	K
813691	Carpet, sill, R.H.		119	
813701	Pad, cushion top		125	
813942	Tubing assembly, motor to wheelbox		64	
815825	Heater assembly	AWS1	103	
815895	Hood, sewn assembly (Black)		114	
815896	Hood, sewn assembly (White)		114	
815951	Panel, dash shelf, L.H.S.		80	
815965	Panel assembly, L.H., L.H.S.		80	
816007	Cover, trim		98	
816008	Cushion pad, rear	BES35	131	
816011	Bracket assembly		98	
816061	Cushion pad, front	BES34	131	
816064	Pad assembly, headrest	BES15	128	
816151	Backboard assembly, trimmed, L.H. (Black)	BES30	131	
816152	Backboard assembly, trimmed, L.H. (Red)	BES30	131	
816153	Backboard assembly, trimmed, L.H. (Light Tan)	BES30	131	
816157	Backboard assembly, trimmed, L.H. (Shadow Blue)	BES30	131	
816161	Backboard assembly, trimmed, R.H. (Black)	BES30	131	
816162	Backboard assembly, trimmed, R.H. (Red)	BES30	131	
816163	Backboard assembly, trimmed, R.H. (Light Tan)	BES30	131	

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
816167	Backboard assembly, trimmed, R.H. (Shadow Blue)	BES30	131	
816331	Headlining assembly (Black)		116	
816421	Board assembly, trim, rear compartment (Black)		121	
816422	Board assembly, trim, rear compartment (Red)		121	
816423	Board assembly, trim, rear compartment (Light Tan)		121	
816427	Board assembly, trim, rear compartment (Shadow Blue)		121	
816499	Panel assembly, front deck		81	
816521	Cover assembly, L.H.S. (Black)		110	
816529	Cover assembly, L.H.S. (White)		110	
816621	Hood, sewn assembly (Black)		114	
816629	Hood, sewn assembly (White)		114	
902367	Windscreen glass		93	K,L
902369	Rubber, glazing	AU4	93	K,L
903097	Outer sill panel, L.H.	AR32	82	K
903098	Outer sill panel, R.H.		82	K
903099	Rear wing, inner panel, L.H.	AR27	81	
903100	Rear wing, inner panel, R.H.	AR26	81	
903134	Heelboard panel	AQ8	78	K
903137	Panel, front wheelarch, outer, L.H.		83	
903138	Panel, front, wheelarch, outer, R.H.		83	K
903148	Panel, wheelarch, outer, L.H.		78	K
903149	Panel, wheelarch, outer, R.H.	AQ16	78	K
903466	Windscreen glass, L.H.S.		93	K,L
903467	Windscreen glass, R.H.S.	AU3	93	K,L
903599	Rubber	BC12	116	
903636	Panel, R.H.S.	AR7	80	
903637	Panel, L.H.S.		80	
903689	Roof assembly, welded	BC1	87	
903892	Frame assembly, L.H.	BE2	124	
903893	Frame assembly, R.H.		124	
904140	Heater assembly	AW1	101	
905692	Door assembly, L.H.	AT1	87	
905693	Door assembly, R.H.		87	
906707	Glass, windscreen		93	
907077	Panel, outer, rear wing, L.H.		81	
907078	Panel, outer, rear wing, R.H.	AR23	81	
907112	Hood frame assembly		112	
907154	Side, front wing, L.H.	AS6	83	
907155	Side, front wing, R.H.	AS5	83	
907157	Panel nose, L.H.	AS17	83	
907158	Panel nose, R.H.	AS16	83	
907163	Panel assembly, front outer, L.H.		78	
907164	Panel assembly, front outer, R.H.	AQ14	78	
907177	Door lock assembly, L.H.		89	G,K
907178	Door lock assembly, R.H.		89	G,K
907254	Bonnet assembly		83	
907257	Plinth, side/flasher lamp, L.H.		85	
907258	Plinth, side/flasher lamp, R.H.		85	
907259	Panel, dash shelf, R.H.S.		80	
907268	Panel, dash shelf, L.H.S.		80	
908025	Door assembly, L.H.		87	
908026	Door assembly, R.H.		87	
908124	Facia panel assembly, L.H.S., U.S.A.		96	
908299	Hood frame assembly (Beige)		112	
910088	Hood frame assembly (Black)		112	

# NUMERICAL INDEX

Part No.	Description	Plate No.	Page	Also Used on Models
910341	Facing assembly, facia, L.H.		97	
910351	Facing assembly, facia, centre		97	
910361	Facing assembly, facia, R.H.		97	
910424	Frame and headrest assembly, L.H. seat	BES1	128	
910425	Frame and headrest assembly, R.H. seat		128	
910430	Padding, seat side, inner, R.H., L.H. seat	BES27	130	
910431	Padding, seat side, inner, L.H., R.H. seat		130	
910432	Padding, outer, L.H.	BES21	129	
910433	Padding, outer, R.H.		129	
910451	Front seat complete assembly, trimmed, leathercloth, L.H. (Black)		127	
910452	Front seat complete assembly, trimmed leathercloth, L.H. (Red)		127	
910453	Front seat complete assembly, trimmed, leathercloth, L.H. (Light Tan)		127	
910457	Front seat complete assembly, trimmed, leathercloth, L.H. (Shadow Blue)		127	
910461	Front seat complete assembly, trimmed, leathercloth, R.H. (Black)		127	
910462	Front seat complete assembly, trimmed, leathercloth, R.H. (Red)		127	
910463	Front seat complete assembly, trimmed, leathercloth, R.H. (Light Tan)		127	
910467	Front seat complete assembly, trimmed, leathercloth, R.H. (Shadow Blue)		127	
910471	Front seat complete assembly, trimmed, leather, L.H. (Black)		128	
910472	Front seat complete assembly, trimmed, leather, L.H. (Red)		127	
910473	Front seat complete assembly, trimmed, leather, L.H. (Light Tan)		127	
910477	Front seat complete assembly, trimmed, leather, L.H. (Shadow Blue)		128	
910481	Front seat complete assembly, trimmed, leather, R.H. (Black)		128	
910482	Front seat complete assembly, trimmed, leather, R.H. (Red)		127	
910483	Front seat complete assembly, trimmed, leather, R.H. (Light Tan)		127	
910487	Front seat complete assembly, trimmed, leather, R.H. (Shadow Blue)		127	
910501	Heater assembly		103	
910504	Heater assembly		101	
950119	Frame assembly	AV1	93	L
CD15685B	Washer		81	A,B,C,D,E,J,P,R,Y
CD22869	Plug		133	A,P,V
CD24152	Washer, cup		118, 120, 121	A,E,K,L,O,Z
CD26326	Mounting pad		86	A,E,G,L
CD25672	Plug, rubber		133	B,K,L,M,P,R,V
CD31481	Touch-in paint (Black)		143	L,Z
CS4009	Clip, bellows	W46	41	A,E,K,L,M,O,Z
CS4011	Clip, supergrip		81	A,E,K,O
CS4012	Clip	E24	12, 81, 101	A,B,E,E-2 litre,K,L,O,P,R,V,Y,Z
CS4014	Clip, hose		101, 103	A,C,D,G,H,A,M,P,R,T,V,Y,Z
CS4020	Clip		41	A,E,K,L,O,Z
CS4024	Clip	AC35	53	K,L,M,O,Z
CS4025	Clip	AC35	53	A,C,E,K,M,O,P,R,V,Z
CS4027	Clip, hose	AW31	102, 104	
CS4038	Clip	AE12	55	L,R